

MULTIFUNCTIONAL DIGITAL SYSTEMS

# Quick Start Guide

---

**e-STUDIO306LP**



# Lineup of Our Manuals

Some of these manuals are printouts and others are PDF files recorded in the User Documentation CD-ROM. In the printouts, precautions and basic operations are described. Be sure to read "Safety Information" before using the equipment. In the PDF files, detailed copying functions and other settings are described. Select and read those best suited to your needs.


## Printouts



### Safety Information

This Safety Information describes the necessary precautions for use. For your added security, be sure to read this booklet first.

PDF files recorded in the "User Documentation CD-ROM".



### Quick Start Guide (This manual)

This Quick Start Guide describes the preparations, basic and advanced usage, maintenance and regular cleaning of the equipment.

PDF files recorded in the "User Documentation CD-ROM".

## How to use the User Documentation CD

### Windows:

1. Set the User Documentation CD in the CD-ROM drive on your computer.  
The browser starts automatically and the menu is displayed.

### Note

If the menu is not displayed, open the User Documentation CD from the explorer and double-click "index.html".

2. Click the cover page or the title of the operator's manual to be viewed from the menu. Its PDF file is displayed.

### Macintosh:

1. Set the User Documentation CD in the CD-ROM drive on your computer.
2. Open the [e-STUDIO Manual] folder in the User Documentation CD and the [PDF] folder.
3. Double-click the file of the operator's manual to be viewed. Its PDF file is displayed.



### **Copying Guide**

This Copying Guide describes the operations and settings enabled with the [COPY] button on the control panel.

### **Scanning Guide**

This Scanning Guide describes the operations and settings enabled with the [SCAN] button on the control panel and those of Internet Fax.

### **e-Filing Guide**

This e-Filing Guide describes the operations and settings enabled with the [e-FILING] button on the control panel and the e-Filing web utility.

This e-Filing web utility enables you to operate e-Filing using the browser on your computer.

### **MFP Management Guide**

This MFP Management Guide describes the operations and settings enabled with the [USER FUNCTIONS] button and the [COUNTER] button on the control panel.

### **Software Installation Guide**

This Software Installation Guide describes the installation procedures for printer drivers and utilities.

### **Printing Guide**

This Printing Guide describes the settings of printer drivers required for printing and the various procedures.

### **TopAccess Guide**

This TopAccess Guide describes procedures for remote setup and management from a web-based utility, "TopAccess".

This "TopAccess" web utility enables you to manage the equipment using the browser on your computer.

### **Troubleshooting Guide**

This Troubleshooting Guide describes how to deal with problems, such as paper jams, as well as how to react to messages displayed on the touch panel.

### **Network Fax Guide**

This Network Fax Guide describes the operations of the N/W-Fax Driver.

The N/W-Fax driver enables you to send electronic documents as faxes or Internet faxes from your computer.

### **High Security Mode Management Guide**

This High Security Mode Management Guide describes the conditions and settings to use the equipment in the high security mode.

### **Help menu for client software**

To run the following client software, refer to the Help menu of each:

- AddressBook Viewer
- e-Filing Backup/Restore Utility
- TWAIN Driver / File Downloader

### **Operator's manuals of options**

In the following options sold separately, the corresponding operator's manuals are co-packed.

- e-STUDIO RD30 User's Guide
- GD-1250/GD-1260/GD-1270 Operator's Manual for FAX Unit
- GN-1060 Operator's Manual for Wireless LAN Module
- GP-1070 Operator's Manual for Data Overwrite Enabler
- KP-2004 Operator's Manual for e-BRIDGE ID Gate
- KP-2005 Operator's Manual for e-BRIDGE ID Gate

### **To read manuals in PDF (Portable Document Format) files**

Viewing and printing manuals in PDF files require that you install Adobe Reader or Adobe Acrobat Reader on your PC. If Adobe Reader or Adobe Acrobat Reader is not installed on your PC, download and install it from the website of Adobe Systems Incorporated.

# How to Read This Manual

## Symbols in this manual

In this manual, some important items are described with the symbols shown below. Be sure to read these items before using this equipment.

**WARNING** Indicates a potentially hazardous situation which, if not avoided, could result in death, serious injury, or serious damage, or fire in the equipment or surrounding objects.

**CAUTION** Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury, partial damage to the equipment or surrounding objects, or loss of data.

**Note** Indicates information to which you should pay attention when operating the equipment.

Read the following description as required.

**Tip** Describes handy information that is useful to know when operating the equipment.




Indicates the pages describing items related to what you are currently doing.


## Description of original/paper direction

Paper or originals of A4 or B5 / LT size can be placed either in a portrait direction or in a landscape direction. In this manual, “-R” is added to this paper size when this size of paper or original is placed in a landscape direction.

Example: A4 / LT size original on the original glass



Placed in a portrait direction: A4 / LT



Placed in a landscape direction: A4-R / LT-R

Paper or originals of A3 or B4 / LD or LG size can only be placed in a landscape direction, therefore “-R” is not added to these sizes.

## Screens and Operation Procedures

- In this manual, the screens and the operation procedures in Windows are described for Windows 7. The details on the screens may differ depending on how the equipment is used, such as the status of the installed options, the OS version and the applications.
- The illustration screens used in this manual are for paper in the A/B format. If you use paper in the LT format, the display or the order of buttons in the illustrations may differ from that of your equipment.

# CONTENTS

Lineup of Our Manuals .....	2
How to Read This Manual .....	2
Notes regarding papers copied or printed with this equipment.....	4
Recommended toner cartridges.....	4

## Chapter 1 PREPARATIONS

Description of Each Component.....	6
Turning Power ON/OFF .....	12
Placing Paper and Originals .....	15
Installing Client Software .....	17

## Chapter 2 BASIC OPERATION

Basic Copying Operation.....	20
Basic Fax Operation.....	24
Basic Scanning Operation.....	28
Basic e-Filing Operation.....	30
Basic Printing Operation .....	32
Basic Menu Operation .....	34

## Chapter 3 MAINTENANCE

Replacing Toner Cartridge .....	36
Regular Cleaning .....	37

## Chapter 4 TROUBLESHOOTING

Troubleshooting.....	40
----------------------	----

## Chapter 5 ADVANCED FUNCTIONS

Advanced Functions .....	44
--------------------------	----

## Chapter 6 INFORMATION ABOUT EQUIPMENT

Items Included in This Product .....	54
Client Utilities CD-ROM .....	55
Client Software .....	56
Options .....	58
Logging in.....	60
Specifications of Equipment .....	63
Specifications of Options.....	65

INDEX .....	67
-------------	----

# Notes regarding papers copied or printed with this equipment

Papers copied or printed using this equipment may need to be handled differently from normal ones due to the nature of the erasable toner. Take note of the following points to avoid problems as a result of using this equipment.

Avoid the following actions as they may discolor the copy or printout.

- Store for long period of time
- Leave in places exposed to high temperature, such as inside of a car
- Leave in places exposed to direct sunlight
- Rub the print side hard with a rubber and the like

Do not use for printing addresses and certificates.

Reusability decreases sharply when paper ends are folded, or paper is torn. Do not keep unnecessary copies or printouts tucked inside notebooks and the like. Erase with e-STUDIO RD30 immediately.

Paper written with normal writing utensils such as ballpoint pens and pencils cannot be erased, and therefore rejected by e-STUDIO RD30. To make a note in a sheet of paper printed by e-STUDIO RD30 use "FriXion" pens made by Pilot Corporation.

e-STUDIO RD30 cannot make the erased information completely invisible. Take extra care when disposing of erased paper.

Do not use paper printed by this equipment and erased by e-STUDIO RD30 in any other multifunction system than this equipment. This may cause malfunction.

## Recommended toner cartridges

To assure optimal printing performance, we recommend that you use only genuine TOSHIBA toner cartridges. If you use a TOSHIBA-recommended toner cartridge, you can utilize the following three functions of this equipment:

- **Cartridge detecting function:**

This function checks if the toner cartridge is correctly installed and notifies you if it is not.

- **Toner remaining check function:**

This function notifies you when there is little toner remaining in the cartridge, as well as notifying it to your authorized service representative automatically by the remote service.

- **Image quality optimization function:**

This function controls image quality according to the characteristics of the toner to be used and enables you to print images of an optimal quality.

If you are using a toner cartridge other than the one we recommend, the equipment may not be able to detect whether it is installed or not. Therefore, even if the toner cartridge is correctly installed, the error message "TONER NOT RECOGNIZED" appears on the touch panel and printing may not be performed. You may also not be able to utilize the image quality optimization function, the toner remaining check function and the remote service function notifying your authorized service representative automatically.

If you are using a toner cartridge other than the one we recommend, toner is not recognized. If this is a problem for you, please contact your service representative. Remember you will not be able to utilize the Toner remaining check function and Image quality optimization function as we mentioned.

# Chapter 1


## PREPARATIONS

Description of Each Component.....	6
Turning Power ON/OFF.....	12
Placing Paper and Originals .....	15
Installing Client Software.....	17

# Description of Each Component

This section describes the names and operations of the equipment, control panel and touch panel.

## Front / Right side



**1. Reversing Automatic Document Feeder (optional, MR-3026)**

The stack of originals is scanned one sheet at a time. Both sides of the originals can be scanned. A maximum of 100 sheets (80 g/m<sup>2</sup> or 20 lb. Bond) can be placed in one go. (The maximum number of sheets that can be set may vary depending on the media type of the originals.)

**2. Operator's Manual Pocket (back side, optional, KK-1660)**

Keep the manual in this pocket.

**3. USB terminal (4-pin)**

Use this terminal when connecting this equipment to a PC with a commercially available USB cable.

**4. Network interface connector**

Use this connector when connecting this equipment to a network.

**5. Automatic duplexing unit**

This unit makes copies on both sides of the paper. Open it when paper jams occur.

**6. Bypass tray**

Use this to perform printing on special media types such as OHP film, etc.

📖 P.23 "Bypass copying" in this manual

**7. Paper holding lever**

Use this to locate paper on the bypass tray.

**8. Paper feed cover**

Open this cover when releasing paper misfed in the drawer feeding area.

**9. Paper feed cover (optional)**

Open this cover when releasing paper misfed in the Paper Feed Pedestal (optional).

**10. Paper size indicator**

The size of the paper set in the drawer can be checked.

**11. Paper Feed Pedestal (optional, KD-1033) and Additional Drawer Module (optional, MY-1042)**

Use the Paper Feed Pedestal to add one drawer. The Additional Drawer Module (optional) can be installed in this device.

**12. Drawer**

A maximum of 550 sheets of plain paper can be placed in one go.

📖 P.15 "Placing paper" in this manual

**13. Front cover**


Open this cover when you replace the toner cartridge and clean the charger.

### Tip

Items marked (optional) are sold separately. In addition to those on P.6 and P.7, you will find more on other pages.

📖 P.58 "Options" in this manual.

## Left / Inner side



### 1. Platen sheet

Use this to hold the original on the original glass to scan it.  
 ⓘ P.37 "Regular Cleaning" in this manual

### 2. Original glass

Use this to copy three-dimensional originals, book-type originals and special paper such as OHP film or tracing paper, as well as plain paper.

### 3. Touch panel

Use this to set and operate various types of functions such as copying, scanning and faxing. This also displays messages, such as when paper runs out or paper jams occur.  
 ⓘ P.10 "Touch panel" in this manual

### 4. Control panel

Use this to set and operate various types of functions such as copying and faxing.  
 ⓘ P.8 "Control panel" in this manual

### 5. Toner cartridge

When toner runs out, the message appears on the touch panel. Replace the cartridge following the procedure below.  
 ⓘ P.36 "Replacing Toner Cartridge" in this manual

### 6. Main power switch

Use this switch to turn the power of the equipment ON or OFF.  
 ⓘ P.12 "Turning Power ON/OFF" in this manual

### 7. Exit support tray

This tray aligns the printed paper.  
 ⓘ *Troubleshooting Guide* (PDF): "Chapter 1: TROUBLESHOOTING FOR THE HARDWARE" - "Removal and Installation of the Exit Support Tray"

### 8. Paper exit stopper

Use this to prevent the exiting paper from falling. Open this when you make many copies or prints on a larger size of paper such as A3, B4, LD and LG.

### 9. Exit tray

Printed paper exits into this tray.

### 10. USB port

Use this connector when printing files stored in a USB device or storing scanned data into the USB device.

### 11. Scanning area

The data of originals transported from the Reversing Automatic Document Feeder (optional) are scanned here.  
 ⓘ P.37 "Regular Cleaning" in this manual


### 12. Original scale

Use this to check the size of an original placed on the original glass.



# Control panel

Use the buttons on the control panel for various operations and settings in the equipment.



## 1. [e-FILING] button

Use this button to access stored image data.

## 2. [COPY] button

Use this button to access the copying function.

## 3. [MENU] button

Use this button to display frequently used templates.

## 4. [USER FUNCTIONS] button

Use this button for paper size or media type setting of drawers, and registration of the copy, scan and fax settings including a default setting change.

*MFP Management Guide* (PDF): "Chapter 1: SETTING ITEMS (USER)"

*MFP Management Guide* (PDF): "Chapter 2: SETTING ITEMS (ADMIN)"

## 5. [INTERRUPT] button

Use this button to interrupt print processing and perform a copy job. The interrupted job is resumed through your pressing this button again.

## 6. [COUNTER] button

Use this button to display the counter.

*MFP Management Guide* (PDF): "Chapter 3: MANAGING COUNTERS (COUNTER MENU)"

## 7. [ENERGY SAVER] button

Use this button for the equipment to enter the energy saving mode.

## 8. ON/OFF lamp

This green lamp lights when the [POWER] button is ON.

## 9. MAIN POWER lamp

This red lamp lights when the main power switch is ON.

## 10. [POWER] button

Use this button to turn the power of the equipment ON or OFF (shutdown).

## 11. Digital keys

Use these keys to enter any numbers such as the number of copies, telephone numbers or passwords.

## 12. [FUNCTION CLEAR] button

When this button is pressed, all selected functions are cleared and returned to the default settings. If the default setting is changed on the control panel, and then copying, scanning, faxing or similar is performed, this button blinks.

## 13. [STOP] button

Use this button to stop any scanning and copying operations in progress.

## 14. [START] button

Use this button to start copying, scanning and faxing operations.

## 15. [CLEAR] button

Use this button to correct the numbers keyed in, such as the number of copy sets.

## 16. Alarm lamp

This red lamp lights when an error occurs and some action needs to be taken.

## 17. PRINT DATA lamp

This green lamp lights during reception of data such as print data.

## 18. [ACCESS] button

Use this button when the department code or user information has been set. If this button is pressed after copying, etc., the next user needs to enter the department code or user information.

P.60 "Logging in" in this manual

## 19. MEMORY RX / LINE lamps

These lamps light in the status of the fax data reception and fax communication. The equipment can be operated even while these lamps are lighting.

**20. [FAX] button**

Use this button to access the Fax / Internet Fax function.

**21. [PRINT] button**

Use this button to access the printing functions such as private printing, in this equipment.

**22. [SCAN] button**


Use this button to access the scanning function.

**23. Touch panel**

Use this panel for the various settings of the copying, scanning and Fax functions. This also displays messages, such as when paper runs out or paper jams occur.

## Adjusting the angle of the control panel

The angle of the control panel is adjustable at any angle between 7 and 84 degrees from the horizontal position.

**CAUTION**


When changing the angle of the control panel, be careful not to catch your hands in the gap between the equipment and the control panel.

This could injure you.

## Touch panel

When the power is turned ON, the basic menu for copying functions is displayed on this touch panel. The status of the equipment is also displayed on the touch panel with messages and illustrations.

The menu shown at the time of turning the power ON can be changed to one for functions other than copying, for example, Fax function. Contact your service technician or representative for details.



### 1. Function display

The function being used, such as copying or faxing, is displayed.

### 2. [?] (HELP) button

Use this button to view the explanation of each function or the buttons on the touch panel.

📖 P.42 "Using the Help functions" in this manual

### 3. [JOB STATUS] button

This indicates the processing status of copy, fax, scan or print jobs, and also allows you to view their performance history.

### 4. Date and time

The present date and time are displayed.

### 5. Alert message indication area

This shows alert messages such as when the toner cartridges must be replaced.

### 6. Message indication area

The explanation of each operation or the current status is displayed in message form.

## Message displayed

The following information appears on the touch panel:

- Equipment status
- Operational instructions
- Cautionary messages
- Reproduction ratios
- Number of copy sets
- Paper size and amount of paper remaining in a selected drawer
- Date and time

## Touch buttons

Press these buttons on the touch panel lightly to set various functions.




## Adjusting the contrast of the touch panel

You can set the contrast of the touch panel in the USER FUNCTIONS menu entered by pressing the [USER FUNCTIONS] button on the control panel.

📖 *MFP Management Guide* (PDF): "Chapter 1: SETTING ITEMS (USER)" - "GENERAL"

# Setting letters

The following menu is displayed when the entry of any letter is required for scanning or e-Filing, etc.  
Use the buttons on the touch panel for letter entry.  
After entering the letters, press [OK]. The menu will be changed.



The following buttons are used for letter entry.

- [Basic]: Press this to access the basic keys.
- [Symbol]: Press this to access the symbol keys.
- [Other]: Press this to access the special keys.

- [Caps Lock]: Press this to switch capital letters and small letters.
- [Shift]: Press this to enter capital letters.
- [Space]: Press this to enter a space.



: Press these to move the cursor.

[Back Space]: Press this to delete the letter before the cursor.

[Clear]: Press this to delete all letters entered.

[CANCEL]: Press this to cancel the entry of letters.


[OK]: Press this to fix all entered letters.

# Turning Power ON/OFF

This section explains how to turn the power ON and OFF as well as the energy saving mode. How to turn the power ON differs between when the MAIN POWER lamp (red) on the control panel is lit and when it is not.


## Turning the power ON

When the MAIN POWER lamp (red) on the control panel does not light:



Open the main power switch cover and turn the power ON there.

When the MAIN POWER lamp (red) on the control panel lights:



Press the [POWER] button.

- The equipment starts warming-up. "Wait Warming Up" appears during warming-up. This may take longer than normally depending on the status and condition.
- While the equipment is warming up, you can use the auto job start function. For details, refer to the following guide:  
[Copying Guide \(PDF\): "Chapter 2: HOW TO MAKE COPIES" - "Making Copies"](#)

The equipment will be ready for copying after about 65 seconds and "READY" appears.

When you turn the power of the equipment OFF, be sure also to shut it down by pressing the [POWER] button on the control panel. Do not simply turn the main power switch OFF. For details, see the following page:

[P.13 "Turning the power OFF \(Shutdown\)" in this manual](#)

### When "ERASING DATA" appears

This message appears when the Data Overwrite Enabler (optional) has been installed. It appears immediately after the power is turned ON or after the equipment has been operated. You can operate the equipment even if it is displayed.

### Tip

When the equipment is controlled under the department or user management function, enter the department code or user information first. For details, see the following page:

[P.60 "Logging in" in this manual](#)


## Turning the power OFF (Shutdown)

When turning the power of the equipment OFF, be sure to shut it down according to the procedure below. Check the following three points before shutdown.

- No jobs should be left in the print job list.
- None of the PRINT DATA lamp or the MEMORY RX / LINE lamps should be blinking.  
(If the equipment is shut down while any of the above lamps is blinking, jobs in progress such as FAX reception will be aborted.)
- No computer should access the equipment via the network, such as TopAccess.

### Notes


- When the ON/OFF lamp (green) lights or blinks on the control panel, do not simply press the main power switch to turn the power OFF. The stored data may be lost or the hard disk may be damaged.
- If a job in process exists when the [POWER] button of the control panel is pressed, "Processing job will be deleted. Are you sure you want to shutdown?" appears.



Press the [POWER] button until a "pip" sound is heard.

"Shutdown is in progress." appears for a while, and then the power is turned OFF.

When the equipment is not used for a long period of time:



Press the [POWER] button on the control panel to shut down the equipment, check that the ON/OFF lamp (green) stops blinking and is definitely not lit, and then turn the power OFF with the main power switch.

When the power is turned OFF with the main power switch, the MAIN POWER lamp (red) will go out.

## Saving energy when not in use – energy saving modes –

This equipment supports three energy saving modes; the Automatic Energy Save mode, Sleep mode and Super Sleep mode. The table below shows the procedures to switch modes manually and the conditions under which the equipment enters into or recovers from each mode.

Energy saving modes	Procedure to switch modes	Conditions to enter into the mode	Status of equipment	Conditions to recover from the mode
Automatic Energy Save mode	When a specified period of time <sup>*1</sup> has passed since the last use of the equipment.	—	"Saving energy - press START button." appears on the touch panel.	When a button on the control panel <sup>*2</sup> is pressed or when print data or fax data are received.
Sleep mode	When the [ENERGY SAVER] button <sup>*3</sup> is pressed or when a specified period of time <sup>*4</sup> has passed since the last use of the equipment.	When a particular option <sup>*5</sup> is installed or when a particular protocol <sup>*6</sup> is enabled.	The touch panel display goes off and the [ENERGY SAVER] button lights in green.	Same as the Automatic Energy Save mode.
Super Sleep mode	When the [ENERGY SAVER] button <sup>*3</sup> is pressed or when a specified period of time <sup>*4</sup> has passed since the last use of the equipment.	When a particular option <sup>*5</sup> is not installed and also when a particular protocol <sup>*6</sup> is disabled.	Only the MAIN POWER lamp (red) lights.	When the [POWER] button is pressed, when print or fax data are received through a wired LAN or when the time set for Scheduled Print has come.

\*1 The default value set at the factory shipment is 1 minute.


\*2 Any of the [START], [ENERGY SAVER], [COPY], [e-FILING], [SCAN], [PRINT] and [FAX] buttons.

\*3 [ENERGY SAVER] button on the control panel.


\*4 The default value set at the factory shipment is 1 minute (The default value set at the factory shipment of the European version is 10 minutes).

\*5 Any of the Wireless LAN Module and e-BRIDGE ID Gate.

\*6 Any of IPX, AppleTalk and other protocols. When the IPsec function is enabled or the Ethernet speed is set to [AUTO (-1000MB)] or [1000BASE FULL], the equipment enters into the Sleep mode. For details, refer to the following guide:

 **TopAccess Guide** (PDF): "Chapter 8: [Administration] Tab Page" - "[Setup] Item list"

For changing the set period of time for entering into each mode, refer to the following guide:

 **MFP Management Guide** (PDF): "Chapter 2: SETTING ITEMS (ADMIN)" - "GENERAL"

### Note

#### For the European version

Contact your service representative to change the default settings noted above.

When the set period of time for switching to the Automatic Energy Save mode is the same as that for the Sleep mode or the Super Sleep mode, the equipment enters into the Sleep mode or the Super Sleep mode after the set period of time.

### Note


If an original is placed on the original glass during the energy saving mode, its size will not be detected even when the equipment is recovered from this mode. After pressing the [START] or [POWER] button to recover from the mode, such as when "READY" is displayed on the basic copying function menu, place it on the glass again.




# Placing Paper and Originals

This section explains how to set paper and originals. Incorrect setting causes image skews or paper jams. Follow the procedure below.


## Placing paper




Pull out the drawer and place paper face up.



Set the end guide so that it matches the paper size.



Set the side guides so that they match the paper size.



Push in the drawer.


### **CAUTION**

Be careful not to catch your fingers when pushing the drawer back.

This could injure you.

### **Note**

- Be sure that the height of the stacked paper does not exceed the MAX line indicated on the side guides. If the paper is curled, turn the curled face down as indicated in the figure.



- When loading paper erased by e-STUDIO RD30, divide the paper into approximately 50 sheets, shuffle well and align before loading into the drawer.


### **Tips**

For paper available for the equipment, see the following page:


📖 P.63 "Specifications of Equipment" in this manual

## Placing originals


### Original glass



1 Raise the Original Cover (optional) or the Reversing Automatic Document Feeder (optional).



2 Place the original with its face down on the original glass and align it against the left rear corner.




3 Lower the Original Cover (optional) or the Reversing Automatic Document Feeder (optional) carefully.

### **CAUTION**


Do not place any heavy objects (4 kg (9 lb.) or over) on the original glass and do not press on it with force.

Breaking the glass could injure you.

### Reversing Automatic Document Feeder (optional)




1 Place the originals face up on the original feeder tray.



2 Align the side guides to the original length.

### Tip

- You need to select the original size by yourself when placing the following originals whose sizes cannot be detected correctly:
  - Highly transparent originals (e.g. overhead transparencies, tracing paper)
  - Totally dark originals or originals with dark borders
  - Non-standard size originals (e.g. newspapers, magazines)
- When placing mixed-size originals on the Reversing Automatic Document Feeder (optional), adjust its side guides to the widest original, and then align the originals against the guide on the front side.



# Installing Client Software

How to install the client software such as the printer driver from the Client Utilities CD-ROM co-packed with the equipment is described as follows.

## Recommended installation

The recommended client software such as the printer driver can be installed all in one go.

- 1** Turn the power ON and confirm that "READY" appears on the touch panel.

P.12 "Turning Power ON/OFF" in this manual

- 2** Insert the Client Utilities CD-ROM in the CD-ROM drive of a Windows computer.

### Tip


To install the client software, log onto Windows with a user account which enables the installation such as "Administrators".

- 3** Select [I agree to the terms of the License Agreement.] and click [Next].

- 4** Click [Recommended].

- 5** Click [Install].

- 6** A list for the discovered printers is displayed. Then **1** select this equipment on the list and **2** click [OK].



Continued on next page

## 7 When the installation is completed, click [Finish].



### Tips

- For details of the Client Utilities CD-ROM, see the following page:  
 P.55 "Client Utilities CD-ROM" in this manual
- For details of the recommended installation, refer to the following guide:  
**Software Installation Guide** (PDF): "Chapter 2: RECOMMENDED INSTALLATION"

## 8 Click [Exit] and then [Yes] to finish the installation.


# Setting the printer driver

Before using the printer driver, you must configure the options installed in the equipment.

## 1 Select [Devices and Printers] in the [Start] menu.

## 2 Select TOSHIBA Universal Printer 2, right-click and then click [Printer Properties].

## 3 The configuration data of the options can be obtained automatically by opening the [Device Settings] tab menu.



## 4 Click [OK]. The setting is completed.

# Chapter 2

## BASIC OPERATION


Basic Copying Operation .....	20
Basic Fax Operation .....	24
Basic Scanning Operation .....	28
Basic e-Filing Operation .....	30
Basic Printing Operation .....	32
Basic Menu Operation.....	34

# Basic Copying Operation

The basic copying procedures, such as enlargement/reduction copying and duplex copying as well as bypass copying, are as follows.


## Making copies

- 1 Press the [COPY] button on the control panel.




- 2 Place the original(s).  
 P.16 "Placing originals" in this manual

- 3 Select the copy modes as required.



- 4
  - 1 Key in the desired number of copies, and then
  - 2 press the [START] button on the control panel. Copying starts.




### Tips


To stop copying, press the [STOP] button on the control panel and then [MEMORY CLEAR] on the touch panel.

## Enlargement and reduction copying

**1** Press [ZOOM].



**2** **1** Select the desired paper size, **2** press [AMS], and then **3** [OK].



### Tip

Align the originals according to the desired paper size and direction. The size of the originals will be automatically determined.

When copying a set of originals whose sizes and directions are different, press [MIXED SIZE].

## Selecting finishing mode (sorting)


**1** Press [FINISHING].



### Tip

When you use the Reversing Automatic Document Feeder (optional), the sorting mode is automatically set.

**2** **1** Press [SORT] and then **2** [OK].






## Setting duplex copy

- 1 Press [2-SIDED].





- 2
  - 1 Select the desired duplex mode and then
  - 2 press [OK].




### Tip

You can choose from 5 types.  
For example, the following settings can be made.


- 1-sided original to 2-sided copy:**  1-2 DUPLEX
- 2-sided original to 2-sided copy:**  2-2 DUPLEX

## Setting original mode

- 1 Press [ORIGINAL MODE].





- 2
  - 1 Select the desired original mode and then
  - 2 press [OK].





### Tip

You can choose from 5 types.  
For example, the following settings can be made.

- Originals with text and photographs mixed:**  TEXT/PHOTO
- Originals printed by this equipment:**  BLUE ORIGINAL

## Density adjustment

You can manually adjust the density by pressing either  or .



### Tip

To lighten the density, press , to darken it, press .

Press [AUTO] to adjust the density automatically.




### Tip

The automatic density adjustment is set by default.


## Bypass copying

- 1 **1** Move the paper holding lever toward the outside and then **2** place paper face down on the bypass tray.




### Note


If the paper is curled, turn the curled face down as indicated in the figure.



- 2 **1** Align the side guides to the paper length and then **2** move the paper holding lever toward the equipment.



- 3 **1** Press the button corresponding to the size of paper set on the bypass tray and then **2** [OK].




- 4 Press the [START] button. Bypass copying starts.

# Basic Fax Operation

The basic procedures for sending a fax (the FAX Unit is optional), such as specifying fax numbers in the address book or setting the transmission conditions, are as follows.

## Sending a fax

- 1 Press the [FAX] button on the control panel.



- 2 Place the original(s).  
 P.16 "Placing originals" in this manual

- 3 Key in the fax number of the recipient by pressing [INPUT FAX No.] on the touch panel or the digital keys on the control panel.



### Tip

If you make a mistake when entering a fax number, press [BACK SPACE] on the touch panel to delete them one by one.  
 Or press the [CLEAR] button on the control panel or [CLEAR] on the touch panel to delete all the numbers you entered.

- 4 Press [SEND] on the touch panel. The fax starts being sent.



### Tip

Alternatively, you can press the [START] button on the control panel to send a fax.

## Specifying recipients in the address book


Specifying recipients one by one

- 1 Press the [SINGLE] tab to display the list of addresses, and then
- 2 the recipient's fax icon.



Specifying recipients in groups

- 1 Press [GROUP] tab to display the list of the groups, and then
- 2 the group name.



### Tips


- You can specify up to a total of 400 recipients (single and group).
- To cancel a selected recipient, press it again.

## Confirming recipients

- 1 Press [DESTINATION].



- 2 The recipient list screen is displayed.



### Tip

Select the recipient you want to delete, and then press [DELETE].




## Setting the transmission conditions

- 1 Press [OPTION].



- 2 The transmission condition setting screen is displayed. Press  $\uparrow$  or  $\downarrow$  to switch the pages.



### Tip

**RESOLUTION:** Set the resolution based on the fineness of the original.  
**ORIGINAL MODE:** When sending originals printed by this equipment, choose [TEXT] to send in the appropriate image quality for the originals.  
**ORIGINAL SIZE:** Set the scan size of the original.


- 3 After each item is set, press [OK].

## Canceling reserved transmissions


- 1 Press [JOB STATUS].



- 2 1 Press [FAX], 2 select the reserved transmission you want to delete, and then 3 press [DELETE].



- 3 Press [DELETE] on the confirmation screen. The reserved transmission is deleted.




## Checking communication status (log)

- 1 Press [JOB STATUS].




- 2
  - 1 Select the [LOG] tab and then
  - 2 press [SEND].



### Tip

Press [RECEIVE] to check the fax reception log.

- 3 The communication status list is displayed. If [OK] is indicated in the "Status", the transmission succeeded.




### Tip

To register recipients in the address book from the send/receive log screen, select the record in the send or receive log, and then press [ENTRY].

## Registering recipients


- 1 Press the [USER FUNCTIONS] button on the control panel and then [ADDRESS] on the touch panel.



- 2
  - 1 Press an open button to create a new recipient and then
  - 2 [ENTRY].



- 3
  - 1 Press each button on the touch panel to enter the following recipient information, and then
  - 2 [OK] to register it.



### Tip

For how to register a group in the address book, see the following page.


**MFP Management Guide (PDF):** "Chapter 1: SETTING ITEMS (USER)" - "Managing Address Book" - "Managing groups in address book"

# Basic Scanning Operation

The basic operation of the scanning function, how to store the scanned data in a shared folder and store these data in a Windows computer is described as follows.


## Storing the scanned data in a shared folder

- 1 Press the [SCAN] button on the control panel.




- 2 Place the original(s).  
 P.16 "Placing originals" in this manual

- 3 Press [FILE] on the touch panel.



- 4
  - 1 Set [FILE NAME],
  - 2 FILE FORMAT, etc. and then
  - 3 press [OK].




- 5 Change the scan settings as required.

### Tip

To scan in the appropriate image quality for originals printed by this equipment, choose [BLUE ORIGINAL] for original mode.

- 6 Press [SCAN] on the touch panel. Scanning starts.




# To store the scanned data of a shared folder in a Windows computer

**1** Start up Windows Explorer.

**2** Enter the name of the shared folder, in which the IP address of the equipment and the scanned data are stored, in the address bar with the following format, and then press the [Enter] button.

**Format:** \\[IP address of the equipment] \file\_share


**e.g.)** When the IP address of the equipment is 172.16.16.110, enter \\172.16.16.110\file\_share in the address bar of Windows Explorer.



## Tips

- For the IP address of the equipment, ask your network administrator.
- It is convenient to make a shortcut of the "file\_share" folder, since step 2 can be omitted.

**3** Store the scanned data in a Windows computer.



## Note

The scanned data stored in the shared folder will be automatically deleted in 30 days by default. Be sure to store them in a Windows computer before that.




# Basic e-Filing Operation

e-Filing is a function to store documents in the hard disk of the equipment, they can then be printed as required.

## Storing documents


The originals are stored as e-Filing documents in the equipment.

- 1 Press the [COPY] button on the control panel.




- 2 Place the original(s).  
 P.16 "Placing originals" in this manual

- 3
  - 1 Press [STORAGE] and then
  - 2 [STORE TO E-FILING] on the touch panel.



- 4
  - 1 Specify the box to be stored and the document name, and then
  - 2 press [OK].



### Tip

When "Print this document?" appears, press [YES] if you want to do this as well as store it.

- 5 Press the [START] button on the control panel to store the documents.

### Tip

You can store documents not only by copying them but also by scanning them or using the printer driver. For details, refer to the following guides:


Scanning Guide (PDF): "Chapter 2: BASIC OPERATION" - "Scan to e-Filing"

Printing Guide (PDF): "Chapter 2: PRINTING FROM WINDOWS" - "Printing with the Best Functions for Your Needs"

# Printing Documents

The procedure for printing documents stored in e-Filing is as follows.

- 1
- Press the [e-FILING] button on the control panel.




- 2
- Select the box on the touch panel that contains the document you want to print.

- 3
- 1

 Select the document you want to print, and then 

2

 press [PRINT]. Printing starts.



## Tip



Selected documents can be previewed in thumbnailed form.

DELETE

Selected documents can be deleted from e-Filing.

SETTINGS

This enables you to make print settings, such as selecting the duplex printing mode or adding page numbers.


TEST PRINT

Specified pages of the document can be printed for confirmation.


# Basic Printing Operation

The basic operation of the Printing function is as follows. This is for printing from a Windows computer with a Universal Printer Driver 2 which needs to be installed in advance.


- 1 Select [Print] in the [File] menu of the application.
- 2 ① Select the printer driver of the equipment, and then ② click [Preferences] ([Properties]).



- 3 Set the print options as required and click [OK].



- 4 Click [Print] ([OK]). Printing starts.



## Tip


To install the printer driver in a Windows computer, refer to the following guide:

📖 P.17 "Installing Client Software" in this manual  
 📖 **Software Installation Guide** (PDF): "Chapter 3: INSTALLING PRINTER DRIVERS FOR WINDOWS"

To install the printer driver in a Macintosh computer, refer to the following guide:

📖 **Software Installation Guide** (PDF): "Chapter 4: INSTALLING PRINTER DRIVERS FOR MACINTOSH"

# Setting Universal Printer 2 Driver



**To specify paper size or number of copy sets**  
Click the [Basic] tab.

**To specify 2-sided printing or N-up printing**  
Click the [Finishing] tab.

**To specify Front cover printing**  
Click the [Paper Handling] tab.

**To adjust Image quality**  
Click the [Image Quality] tab.

**To print with character strings or graphics on the background of the paper**  
Click the [Effect] tab.

**To set not to print blank pages**  
Click the [Others] tab.

**To print with templates**  
Click the [Templates] tab.


# Basic Menu Operation

Press the [MENU] button on the control panel to use templates and check the print counter.

When the user management function is enabled, log in and press the [MENU] button on the control panel. The menu screen for a logged in user is displayed.

You can register frequently used templates, a group of templates or the shortcut of the External Interface Enabler (GS-1020, optional). Registration or deletion of the shortcut can also be enabled in the TopAccess mode. For details, refer to the following guide:

**TopAccess Guide** (PDF): "Chapter 9: [My Account] Tab Page"



- 1. User name display area**  
The name of the user logging in is displayed.
- 2. [EXTENSION] button**  
This is enabled when the External Interface Enabler (GS-1020, optional) is installed. Contact your service technician or representative for details.
- 3. Role information displayed area**  
Available role information for a user who has logged in is displayed.
- 4. Total print counter**  
The total print counter of the user logging in is displayed. Available printing numbers are displayed depending on the settings of the equipment.
- 5. [USER] button**  
The shortcut which a user logging in can employ is displayed.
- 6. [PUBLIC] button**  
The shortcut which all users can employ is displayed.
- 7. Shortcut display area**  
The shortcut registered in the menu screen is displayed.

## Note

According to the authority for each user, the mark or appears on the icons in the role information displayed area. The functions with the mark cannot be used. Some of the functions with the mark cannot be used.

## Tips

- You can create a template with several functions that are frequently used so that they can be employed whenever you want, thus eliminating the need to perform complicated settings every time. Templates can be used in copying, scanning and sending a fax. For details, refer to the following guides:  
**Copying Guide** (PDF): "Chapter 6: TEMPLATES"  
**TopAccess Guide** (PDF): "Chapter 5: [Registration] Tab Page" - "[Registration] Tab Page Overview"
- When the user management function is not used, the public template group and the total print counter are displayed.
- [USER] and [PUBLIC] are displayed when the user management function is enabled.


# **Chapter 3**

## **MAINTENANCE**


Replacing Toner Cartridge.....	36
Regular Cleaning.....	37

# Replacing Toner Cartridge


When "Install new toner cartridge" appears on the touch panel, replace the toner cartridge according to the following procedures.




Open the front cover and then hold down the lever to take off the toner cartridge.




Shake the new toner cartridge well to loosen the toner inside.




Pull out the seal.



Install the new toner cartridge.



Clean the charger.



Close the front cover.

## WARNING

Never attempt to incinerate toner cartridges.

Dispose of used toner cartridges and waste toner boxes in accordance with local regulations.



# Regular Cleaning


Poor quality printing such as uneven and soiled images can be improved by simple cleaning. This section describes the cleaning methods for the equipment.

## Cleaning for the scanning area, original glass, guide and platen sheet

We recommend you to clean the following items weekly, so that the originals can be scanned in unsoiled conditions. Be careful not to scratch the parts that you are cleaning.

### Notes

- Be careful not to scratch the portions in cleaning.
- When cleaning the surface of the equipment, do not use such organic solvents as thinner or benzine.
  - This could warp the shape of the surface or leave it discolored.
- When using a chemical cleaning pad to clean it, follow the instruction.



### 1. Scanning area (surface of the long rectangular glass) / 2. Original glass

Wipe it with a soft dry cloth. If there are still stains remaining, wipe clean with a piece of soft cloth which has been moistened with water and then squeezed well.

Do not use liquids other than water (such as alcohol, organic solvents or neutral detergent).


### 3. Guide / 4. Platen sheet

Clean the surface as follows depending on the staining.


- Clean it with a soft cloth.
- Clean it with a soft cloth lightly moistened with water.
- Clean it with a soft cloth lightly moistened with alcohol, and then wipe it with a dry cloth.
- Clean it with a soft cloth lightly moistened with watered-down neutral detergent, and then wipe it with a dry cloth.

## Cleaning the charger


If the inside of the charger is dirty, the dirt will be transferred to the copied image. Clean the charger following the procedure below.



Open the front cover.



Holding the knob provided for cleaning, pull out the knob carefully until it comes to a stop. Then return the knob to the original position. Repeat this procedure several times.



Close the front cover.

### Notes


When department management and user management are not used, the template in the public template group and the total print counter in the equipment are displayed.

# Chapter 4

## TROUBLESHOOTING

Troubleshooting .....	40
-----------------------	----


# Troubleshooting

When problems such as paper jams occur, see the following explanation or refer to the *Troubleshooting Guide* (PDF) according to  P.41 "References to the Troubleshooting Guide" in this manual.


## Symbols and messages appear on the touch panel


Symbols or messages of such as for paper jams occasionally appear on the touch panel.

For details of the paper jam symbols, refer to the following guide:

 *Troubleshooting Guide* (PDF): "Chapter 1: TROUBLESHOOTING FOR THE HARDWARE" - "Clearing a Paper Jam"

For details of the messages on the touch panel, refer to the following guide:

 *Troubleshooting Guide* (PDF): "Chapter 1: TROUBLESHOOTING FOR THE HARDWARE" - "Messages Displayed on the Touch Panel"




## When paper jams occur

When paper jams occur, refer to the guidance displayed on the touch panel of the equipment or refer to the following guide:

 *Troubleshooting Guide* (PDF): "Chapter 1: TROUBLESHOOTING FOR THE HARDWARE" - "Clearing a Paper Jam"

## Covers of the equipment and the options

The covers of the equipment and the options to be opened when paper jams occur are as indicated by the arrows in the following illustrations.



## About Troubleshooting Guide

The *Troubleshooting Guide* (PDF) describes the causes and the troubleshooting of problems when you use the equipment.


### References to the Troubleshooting Guide


Chapter	Title	Section
Chapter 1	TROUBLESHOOTING FOR THE HARDWARE	When This Screen Is Displayed
		Messages Displayed on the Touch Panel
		Clearing a Paper Jam
		Clearing a Staple Jam
		Replacing a Toner Cartridge
		Refilling With Staples
		Cleaning the Charger
		Cleaning the Hole Punch Dust Bin
		Removal and Installation of the Exit Support Tray
Chapter 2	TROUBLESHOOTING FOR COPYING	Copying Problems
Chapter 3	TROUBLESHOOTING FOR PRINTING	Print Job Problems
		Printer Driver Problems
		Network Connection Problems
		Client Problems
		Hardware Problems
Chapter 4	TROUBLESHOOTING FOR SCANNING	Scanning Problems
Chapter 5	TROUBLESHOOTING FOR e-Filing	e-Filing Web Utility Problems
Chapter 6	TROUBLESHOOTING FOR NETWORK CONNECTIONS	Locating the Equipment in the Network
		LDAP Search and Authentication Problems
		Printing Problems (Network Related)
		Network Fax (N/W-Fax) Driver Problems
		Client Software Authentication Problems
Chapter 7	CHECKING THE EQUIPMENT STATUS WITH TopAccess	Hardware Status Icons on TopAccess [Device] Tab
		Error Messages
		Error Codes
Chapter 8	WHEN SOMETHING IS WRONG WITH THE EQUIPMENT	When You Think Something Is Wrong With the Equipment
		Regular Maintenance

## Error codes

Press [JOB STATUS] and then the [LOG] tab on the touch panel; the LOG menu is displayed. The job history and error codes are displayed in the LOG menu.


For details of the error codes, refer to the following guide:


 **Troubleshooting Guide** (PDF): "Chapter 7: CHECKING THE EQUIPMENT STATUS WITH TopAccess" - "Error Codes"




User Name	Date,Time	Paper	Pages	Sets
---	10,13,19	A4	1	1
---	10,13,18	A4	2	1
---	10,13,18	A4	1	1
---	10,13,18	A4	1	1
---	10,13,16	A4	1	1

## Using the Help functions

If you press  on the upper right of the touch panel, explanations of the functions and buttons on the screen are displayed.

If you press  on the lower left of the Help screen, supplementary information about the functions appears.



# Chapter 5

## ADVANCED FUNCTIONS

Advanced Functions .....	44
--------------------------	----




# Advanced Functions

In Chapter 2 in this manual, the basic functions are described. This section describes the advanced functions to help you get the best out of your equipment.

## Examples of the advanced functions describing in this section

### Copying blue originals more clearly




P.45 in this manual

### Copying or scanning originals without blank sheets




P.46 in this manual

### Storing data in a shared folder as well as sending a fax




P.47 in this manual

### Registering frequently used scan settings in templates




P.48 in this manual

### Attaching the scanned data to an E-mail




P.49 in this manual

### Adding date and time to document files



P.50 in this manual

### Printing a PDF file stored in the USB device



P.51 in this manual

### Printing only allowed data set on the control panel



P.52 in this manual

COPY


FAX

SCAN

e-FILING

PRINT


## Copying blue originals more clearly




The procedure for copying documents printed by this equipment using erasable toner more clearly is as follows.

- 1** Place the original(s).  
 P.16 "Placing originals" in this manual

- 2** Press [ORIGINAL MODE] on the touch panel.



- 3** **1** Press [BLUE ORIGINAL] on the touch panel, and then **2** [OK].



- 4** Press the [START] button on the control panel. Copying starts.

COPY


FAX

SCAN

e-FILING

PRINT


## Copying or scanning originals without blank sheets



You can copy or scan originals omitting blank sheets while maintaining the original page sequence.

### When copying


- 1** Place the originals on the Reversing Automatic Document Feeder (optional).  
 P.16 "Placing originals" in this manual
- 2** Press the [EDIT] tab, and then in the basic menu for the copying functions.
- 3** Press [OMIT BLANK PAGE] and then [OK].



- 4** Press the [START] button on the control panel. Copying starts.

### When scanning

- 1** Place the originals on the Reversing Automatic Document Feeder (optional).  
 P.16 "Placing originals" in this manual
- 2** Press [SCAN SETTING], and then in the basic menu for the scanning functions.
- 3** Press **1** [ON] in the "OMIT BLANK PAGE" setting and then **2** [OK].



- 4** In the basic menu for the scanning functions, specify details such as the destination for saving the data.
- 5** Press [SCAN] on the touch panel. Scanning starts.

COPY


FAX

SCAN

e-FILING

PRINT

## Storing data in a shared folder as well as sending a fax




You can store documents in a shared folder in the equipment or in a computer connected to the network as well as sending a fax.

- 1** Place the original(s).  
 P.16 "Placing originals" in this manual

- 2** Press [STORAGE] on the touch panel.



- 3** **1** Specify details such as the file name, shared folder and file format and then **2** press [OK].



- 4** Specify the recipient and press [SEND]. Sending a fax starts.

COPY


FAX

SCAN

e-FILING

PRINT


## Registering frequently used scan settings in templates



If you register frequently used scan settings in templates, you can easily perform scan operations only by recalling the templates. How to register scan settings (scan data are stored in PDF format in a shared folder) in templates (PUBLIC TEMPLATE GROUP) is described here.

**1** Press [FILE] on the touch panel.


**2** **1** Select "PDF" in the file format, and then **2** press [OK].



**3** Change the scan setting as required.

**4** Press [TEMPLATE] on the touch panel, and then [REGISTRATION] tab.

**5** **1** Press [PUBLIC TEMPLATE GROUP] on the touch panel, and then **2** [OPEN].




**6** Press [PASSWORD], enter the administrator password and press [OK].

**7** **1** Select an empty template button, and then **2** press [SAVE].



**8** **1** Make the settings such as the template name, and then **2** press [SAVE] to complete the registration.



COPY


FAX

SCAN

e-FILING


PRINT

## Attaching the scanned data to an E-mail




The procedure for attaching the scanned data to an E-mail and sending it to the specified E-mail address is as follows.

- 1** Place the original(s).  
 P.16 "Placing originals" in this manual
- 2** Press [E-MAIL] and then [TO] on the touch panel.
- 3** **1** Specify the E-mail address and then **2** press [OK].



- 4** Define the settings for the file as required and then press [OK].
- 5** Press [SCAN] on the touch panel. Scanning starts.



COPY


FAX

SCAN

e-FILING

PRINT


## Adding date and time to document files



The procedure for printing a document file stored in e-Filing with the date and time added at the bottom is as follows.


**1** Select the box in which the desired document is stored.

**2** **1** Select the document and then **2** press [SETTINGS].



**3** Press [TIME STAMP].

**4** **1** Press [LOWER] and then **2** [OK].



**5** Press [PRINT] on the touch panel. Printing starts.



COPY


FAX

SCAN

e-FILING


PRINT

## Printing a PDF file stored in the USB device



The procedure for printing 1 set of a PDF file stored in the USB device is as follows.


- 1** Connect the USB device to the USB port.



- 2** Press the [PRINT] button on the control panel.

- 3** Click the pull-down menu, and then select [USB].

- 4** **①** Select a PDF file to be printed and then **②** press [PRINT]. Printing starts.



### Tips

- Press [SETTINGS], then you can set such as duplex printing.
- The following types of files are also available for printing:
  - JPEG file
  - PRN file
  - PS file
  - XPS file

COPY


FAX

SCAN

e-FILING


PRINT

## Printing only allowed data set on the control panel



The procedure for printing only allowed data set on the control panel is as follows. This will stop you from forgetting to remove printed sheets.

- 1** Open a file to be printed on a Windows computer, and then select [Print] from the file menu of the application.
- 2** Select the printer driver of the equipment, and then click [Preferences] ([Properties]).
- 3** Select "Hold Print" for the job type in the [Basic] tab menu.




- 4** Click [OK] to return to the print dialog box and then [Print] ([OK]).
- 5** Press the [PRINT] button on the control panel of the equipment.

- 6** Click the pull-down menu, and then select [HOLD].

- 7** Select the user name, and then press [OK].

- 8** **1** Select the file to be printed and then **2** press [PRINT]. Printing starts.



# **Chapter 6**


## **INFORMATION ABOUT EQUIPMENT**

Items Included in This Product.....	54
Client Utilities CD-ROM.....	55
Client Software .....	56
Options.....	58
Logging in.....	60
Specifications of Equipment.....	63
Specifications of Options.....	65

# Items Included in This Product

The following items are co-packed with the equipment. Check that you have them all. Contact your service technician or representative if any are missing or damaged.

## Items included in this product

<b>Safety Information</b>	The Safety Information describes the necessary precautions for use. For your added security, be sure to read this booklet first.
<b>Quick Start Guide (This manual)</b>	The Quick Start Guide describes the preparations, basic and advanced usage, maintenance and regular cleaning of the equipment.
<b>Client Utilities CD-ROM</b>	The Client Utilities CD-ROM contains the client software such as the printer drivers and the utility software. For details, see the following page:  P.55 "Client Utilities CD-ROM" in this manual
<b>User Documentation CD-ROM</b>	The User Documentation CD-ROM contains pdf files of the Operator's Manuals such as the Copying Guide and the Troubleshooting Guide.


# Client Utilities CD-ROM

The Client Utilities CD-ROM contains the following client software such as the printer drivers and the utility software.

Client software	
For Windows	Client Software Installer
	Universal Printer 2 Driver
	Universal PS3 printer driver
	Universal XPS printer driver
	TWAIN driver
	File downloader
	N/W-Fax driver
	AddressBook Viewer
	Remote Scan driver
	WIA driver
	e-Filing Backup/Restore Utility
For Macintosh	The PPD file and plug-ins used for Macintosh on the Mac OS X 10.4.x to Mac OS X 10.6.x The PPD file and plug-ins used for Macintosh on the Mac OS X 10.7 or later
For UNIX/Linux	UNIX/Linux filter (Solaris, HP-U, AIX, Linux, SCO)
	CUPS

## Tips

For installing the client software, refer to the following guide:

 **Software Installation Guide** (PDF): "Chapter 1: OVERVIEW"













For details of the client software, see the following page:

 P.56 "Client Software" in this manual




# Client Software

This section describes the outlines of the client software of the equipment. It is necessary to install software except e-Filing Web utility and TopAccess in the computer before it is used.





## Client software for the printing functions

<b>Universal Printer 2 Driver</b>	This Universal Printer 2 Driver is installed with the Recommended Installation. This driver is generally used. For details, refer to the following guides:  <b>Software Installation Guide</b> (PDF): "Chapter 2: RECOMMENDED INSTALLATION" or "Chapter 3: INSTALLING PRINTER DRIVERS FOR WINDOWS"  P32 "Basic Printing Operation" in this manual  <b>Printing Guide</b> (PDF): "Chapter 2: PRINTING FROM WINDOWS"
<b>Universal PS3 printer driver</b>	This driver enables you to print documents in the high quality mode with applications such as Adobe Systems Incorporated. For details, refer to the following guides:  <b>Software Installation Guide</b> (PDF): "Chapter 2: RECOMMENDED INSTALLATION" or "Chapter 3: INSTALLING PRINTER DRIVERS FOR WINDOWS"  <b>Printing Guide</b> (PDF): "Chapter 2: PRINTING FROM WINDOWS"
<b>Universal XPS printer driver</b>	This printer driver enables you to print documents from the WPF applications created for Windows Vista, Windows 7, or Windows 8. For details, refer to the following guides:  <b>Software Installation Guide</b> (PDF): "Chapter 2: RECOMMENDED INSTALLATION" or "Chapter 3: INSTALLING PRINTER DRIVERS FOR WINDOWS"  <b>Printing Guide</b> (PDF): "Chapter 2: PRINTING FROM WINDOWS"
<b>PPD file for Macintosh</b>	This printer driver enables you to print documents from Macintosh computers (Mac OS X 10.4 to Mac OS X 10.8.x). For details, refer to the following guides:  <b>Software Installation Guide</b> (PDF): "Chapter 4: INSTALLING PRINTER DRIVERS FOR MACINTOSH"  <b>Printing Guide</b> (PDF): "Chapter 3: PRINTING FROM Macintosh"
<b>UNIX/Linux filter</b>	UNIX/Linux filter enables you to print documents from the UNIX/Linux workstation. For details, refer to the following guides:  <b>Software Installation Guide</b> (PDF): "Chapter 5: INSTALLING PRINTER DRIVERS FOR UNIX/Linux"  <b>Printing Guide</b> (PDF): "Chapter 4: PRINTING FROM UNIX/Linux"
<b>CUPS</b>	CUPS file enables you to set up the CUPS print system from UNIX/Linux workstation. For details, refer to the following guide:  <b>Software Installation Guide</b> (PDF): "Chapter 5: INSTALLING PRINTER DRIVERS FOR UNIX/Linux"


## Client software for the scanning functions

<b>Remote Scan driver</b>	This driver enables you to scan documents remotely and obtain scanned data as an image in the applications supporting TWAIN on Windows computers. For details, refer to the following guide:  <b>Software Installation Guide</b> (PDF): "Chapter 2: RECOMMENDED INSTALLATION" or "Chapter 6: INSTALLING SCAN DRIVER AND UTILITIES"
<b>WIA driver</b>	This driver enables you to scan documents remotely and obtain scanned data as an image in the applications supporting WIA (Windows Imaging Acquisition) on Windows computers. For details, refer to the following guides:  <b>Software Installation Guide</b> (PDF): "Chapter 2: RECOMMENDED INSTALLATION" or "Chapter 6: INSTALLING SCAN DRIVER AND UTILITIES"  <b>Scanning Guide</b> (PDF): "Chapter 5: OTHER SCANNING METHODS"




## Client software for the e-Filing functions

<b>TWAIN driver</b>	This driver enables you to obtain documents stored in e-Filing as an image in application supporting TWAIN on Windows computers. For details, refer to the following guide:  <b>Software Installation Guide</b> (PDF): "Chapter 2: RECOMMENDED INSTALLATION" or "Chapter 6: INSTALLING SCAN DRIVER AND UTILITIES"
<b>File downloader</b>	File downloader enables you to obtain documents stored in e-Filing as an image in your Windows computer. For details, refer to the following guide:  <b>Software Installation Guide</b> (PDF): "Chapter 2: RECOMMENDED INSTALLATION" or "Chapter 6: INSTALLING SCAN DRIVER AND UTILITIES"
<b>e-Filing Web utility</b>	This utility enables you to operate or make settings for e-Filing using a browser on your computer. Since this utility has been already installed to the equipment, enter the IP address of the equipment into a browser and turn on the power. For details, refer to the following guide:  <b>e-Filing Guide</b> (PDF): "Chapter 3: OVERVIEW ON e-FILING WEB UTILITY"
<b>e-Filing Backup/Restore Utility</b>	This utility enables you to back up and restore the data stored in e-Filing. For details, refer to the following guide:  <b>Software Installation Guide</b> (PDF): "Chapter 8: INSTALLING e-FILING BACKUP/RESTORE UTILITIES"

## Client software for the network management functions

<b>TopAccess</b>	TopAccess enables you to view the device information, display logs, create templates and an address book, and manage the equipment using a browser. Since TopAccess has been already installed to the equipment, enter the IP address of the equipment into a browser and turn on the power. For details, refer to the following guide:  <b>TopAccess Guide</b> (PDF): "Chapter 1: OVERVIEW"
------------------	--


## Client software for the network fax functions

<b>N/W-Fax driver</b>	This driver enables you to send faxes or Internet faxes from your computer. For details, refer to the following guides:  <b>Software Installation Guide</b> (PDF): "Chapter 2: RECOMMENDED INSTALLATION" or "Chapter 7: INSTALLING NETWORK FAX UTILITIES"  <b>Network Fax Guide</b> (PDF): "Chapter 1: OVERVIEW"
<b>AddressBook Viewer</b>	This viewer enables you to manage the address book (such as fax numbers and E-mail addresses) and upload the address book from your computer to the equipment. For details, refer to the following guide:  <b>Software Installation Guide</b> (PDF): "Chapter 2: RECOMMENDED INSTALLATION" or "Chapter 7: INSTALLING NETWORK FAX UTILITIES"



# Options

The following options are sold separately, and upgrade the performance of the equipment if installed. For details, contact your service technician or representative.



- 1. Original Cover (KA-1640PC)**  
This is used to hold an original.
- 2. Reversing Automatic Document Feeder (MR-3026)**  
This unit automatically feeds a stack of originals one by one to have them copied.
- 3. Job Separator (MJ-5009)**  
Enables Faxes, copies and prints to be output onto separate paper trays.
- 4. Paper Feed Pedestal (KD-1033)**  
Use the Paper Feed Pedestal to add one drawer. This pedestal enables you to install the Additional Drawer Module (optional, MY-1042).
- 5. Additional Drawer Module (MY-1042)**  
This drawer can be added to the Paper Feed Pedestal (optional, KD-1033). Combined with the 2 drawers in the equipment, paper can be fed from 4 drawers in total.
- 6. Paper Reusable Device (e-STUDIO RD30)**  
This device enables you to erase paper printed by the equipment.

Other options available are as follows. Contact your service technician or representative for details.

## Work Table (KK-4550)

This is a small table for placing originals while the equipment is being operated.

Installed on the right-hand side of the equipment.

## FAX Unit (GD-1250)

This is a unit for using the equipment as a Fax machine.

Installed inside of the equipment.

## 2nd Line for FAX Unit (GD-1260)

This unit enables you to add a line to the Fax, making a 2nd line available.

- Installed inside of the equipment.
- The FAX Unit (optional, GD-1250) is required.

## Desk (MH-2520)

This is a desk for the equipment.

## Accessible Arm (KK-2550)

This enables a user in a wheelchair to close the Reversing Automatic Document Feeder (MR-3026) while remaining seated.

P.59 "How to use the Accessible Arm" in this manual

## Operator's Manual Pocket (KK-1660)

Keep the manual in this pocket.

## Wireless LAN Module (GN-1060)

This module enables the equipment to be used in a wireless LAN environment.

- Installed inside of the equipment.
- The Antenna (optional, GN-3010) is required.
- The equipment cannot be connected to the wireless and wired LAN at the same time.

## Antenna (GN-3010)

This is used when the Wireless LAN Module is installed.

## e-BRIDGE ID Gate (KP-2004, KP-2005)

You can log in and use the equipment simply by holding the IC card over the e-BRIDGE ID Gate.

- Installed on the right-hand side of the equipment.

## Data Overwrite Enabler (GP-1070)

This is an enabler to erase the data stored temporarily when copying, printing, scanning, faxing, Internet Fax or network Fax is performed. It overwrites temporarily stored data with random data.

## IPsec Enabler (GP-1080)

This enables the IPsec function in this equipment.

## Meta Scan Enabler (GS-1010)

This enables the Meta Scan function in this equipment.

## External Interface Enabler (GS-1020)

This enables the EWB function in this equipment.

## Unicode Font Enabler (GS-1007)


This enables printing from the SAP environment using Unicode font with this equipment.

## Note


Depending on the model, options have been already installed and the functions can be used.

## How to use the Accessible Arm

A person in a wheelchair can close the Reversing Automatic Document Feeder (optional, MR-3026) using the Accessible Arm (optional, KK-2550).



Hold the Accessible Arm.



Hook the Accessible Arm on the right-hand side of the Reversing Automatic Document Feeder to close it.


# Logging in

When the equipment is controlled under department or user management, copying and other functions can be performed if you log in according to the following procedure.

## Department management

You can restrict users or manage copy volumes made by an individual group or department in your company using the department codes. When the equipment is controlled under the department code, turn the power on and enter the code.

When the power of the equipment is turned ON, the following menu appears.



### Tips

Automatic function clear:

- This function returns all settings to default without the need to press the [FUNCTION CLEAR] button on the control panel. It works when a specified period of time has passed since the last paper exit or the last entry of any button. When department or user management is being used, the display returns to the department code or user information input menu. When they are not being used, the display returns to the basic menu for the copying function.
- The period is set at 45 seconds by default at the time of installation of the equipment. To change the setting, refer to the following guide:  
[MFP Management Guide \(PDF\): "Chapter 2: SETTING ITEMS \(ADMIN\)" - "GENERAL"](#)
- When connecting to equipment with department or user management enabled using client software, you may need to log in. For details, ask your administrator.

Key in a department code (max. 63 digits) previously registered and press [OK] on the touch panel. The menu will switch and the equipment will be ready for use.

If the department code keyed in is incorrect, the menu does not change. Key in the correct one.

### After the operation

To prevent unauthorized use of the equipment, return the display to the department code input menu by following either of the procedures below after you finish all operations.

- Press the [ACCESS] button on the control panel.
- Press the [FUNCTION CLEAR] button on the control panel twice.

# User management

You can restrict users or manage available functions and past records by means of user management. When the equipment is managed under this function, turn the power ON and enter the information required (e.g. user name, password). Enter the information according to the procedure below.

## Note

If you enter an invalid password several times, you may not log in for a certain period since it will be regarded as an unauthorized access.

When “User account is locked” or “User Name and Password are not recognized.” appears and logging in cannot be performed, ask your administrator.

## Tips

- If a guest user is enabled in the user management function, [GUEST] is displayed on the touch panel. Press [GUEST] to log in as a guest user. For the types of functions available, consult the administrator.
- When prompted for a PIN code, enter it (up to 32 digits) using the digital keys on the control panel. For details, ask your administrator.

## After the operation

To prevent unauthorized use of the equipment, return the display to the user authentication input menu by logging off with the procedure below after you finish all the operations.

1. Perform either of the operations below.
  - Press the [ACCESS] button on the control panel.
  - Press the [FUNCTION CLEAR] button on the control panel twice.
2. When “Would you like to log out?” appears on the touch panel, select [YES].

- 1** The menu for user authentication appears.

#### MFP local authentication

#### Windows Domain authentication, LDAP authentication

The domain name previously set by the network administrator is displayed in [DOMAIN]. For LDAP authentication, the LDAP server name is displayed in [LDAP] instead of [DOMAIN].

### Tip

If the displayed domain name or LDAP server name is not yours, press ▼ to select one belonging to you.

- 2** Press [USER NAME].

- 3** Enter the user name (maximum 128 letters) and then press [OK].

- 4** Press [PASSWORD].

- 5** Enter the password (maximum 64 letters) and then press [OK].

- 6** Press [OK].

- 7** The equipment becomes being ready to perform copying and other functions.

# Specifications of Equipment

This section describes the types of acceptable paper, sheet capacity of each feeder and the specifications of the equipment.

## Acceptable paper

Feeder	Media type	Weight	Maximum sheet capacity	Paper size
Drawers	PLAIN	64 - 80 g/m <sup>2</sup> 17 - 20 lb. Bond	600 sheets (64 g/m <sup>2</sup> , 17 lb. Bond) 550 sheets (80 g/m <sup>2</sup> , 20 lb. Bond)  Reused paper *1 Stack height 60.5 mm (2.38") or less (Approx. 480 sheets)	A/B format: A3, A4, A4-R, A5-R, B4, B5, B5-R, FOLIO  LT format: LD, LG, LT, LT-R, ST-R, COMP, 13" LG, 8.5" SQ  K format: 8K, 16K, 16K-R
Bypass tray	PLAIN	64 - 80 g/m <sup>2</sup> 17 - 20 lb. Bond	100 sheets (64 g/m <sup>2</sup> , 17 lb. Bond) 100 sheets (80 g/m <sup>2</sup> , 20 lb. Bond)  Reused paper *1 Stack height 5.5 mm (0.20") or less (Approx. 40 sheets)	A/B format: A3, A4, A4-R, A5-R, B4, B5, B5-R, FOLIO  LT format: LD, LG, LT, LT-R, ST-R, COMP, 13" LG, 8.5" SQ  K format: 8K, 16K, 16K-R  Non-Standard size: Length: 100 - 297 mm (3.9 - 11.7"), Width: 148 - 432 mm (5.8 - 17")

\*1 Paper printed by e-STUDIO306LP and erased by e-STUDIO RD30.

## Recommended paper for each media type

Media Type	Toshiba recommendations/Manufacturer	Weight
PLAIN	A/B format: TGIS Paper/Mondi LT format: TIDAL/Hammermill	80 g/m <sup>2</sup> , 20 lb. Bond

## e-STUDIO306LP Specifications


<b>Model name</b>		DP-3030
<b>Type</b>		Desktop type
<b>Original glass</b>		Fixed
<b>Printing (copying) system</b>		Indirect electrophotographic method
<b>Developing system</b>		2-component magnetic brush developing
<b>Fixing method</b>		Halogen lamp (3 pieces)
<b>Photosensor type</b>		OPC
<b>Original scanning system</b>		Flat surface scanning system (When the Reversing Automatic Document Feeder is installed: Fixed scanning system by feeding the original)
<b>Original scanning sensor</b>		Linear CCD sensor
<b>Scanning light source</b>		LED lamp
<b>Resolution</b>	<b>Scanning</b>	600 dpi x 600 dpi
	<b>Writing</b>	2400 dpi x 600 dpi (Smoothing process)
<b>Acceptable originals</b>		Sheets, books and 3-dimensional objects
<b>Acceptable original size</b>		Max. A3 or LD
<b>Acceptable copy paper size</b>	<b>Drawer</b>	A3, A4, A4-R, A5-R, B4, B5, B5-R, FOLIO, LD, LG, LT, LT-R, ST-R, COMP, 13"LG, 8.5"SQ, 8K, 16K, 16K-R
	<b>Bypass</b>	Paper size within 100 - 297 mm (3.94" - 11.69") (Length), 148 - 432 mm (5.83" - 17.01") (Width)
<b>Acceptable copy paper weight</b>	<b>Drawer</b>	64 - 80 g/m <sup>2</sup> (17 - 20 lb. Bond)
	<b>Bypass</b>	64 - 80 g/m <sup>2</sup> (17 - 20 lb. Bond)
<b>Warm-up time</b>		Approx. 65 seconds
<b>First copy time (A4 or LT portrait)</b>		4.9 seconds
<b>Continuous copy speed</b>		Refer to the Copying Guide.
<b>Multiple copying</b>		Up to 999 sheets (digital key entry)
<b>Excluded image width</b>	<b>Copy/Printer</b>	Leading edge: 4.2 mm + 2.8 mm / -1.2 mm (0.17" + 0.11" / -0.05"), Trailing edge: 4.2 mm + 2.8 mm / -1.2 mm (0.17" + 0.11" / -0.05"), Both edge: 4.2 mm + 2.8 mm / -1.2 mm (0.17" + 0.11" / -0.05")
<b>Reproduction ratio</b>	<b>Actual size</b>	100±0.5%
	<b>Zoom</b>	25 - 400% (in 1% increments) For the Reversing Automatic Document Feeder 25 - 200% (in 1% increments)
<b>Paper supply</b>	<b>Drawer</b>	Approx. 550 sheets (Reused paper *1 Stack height 60.5 mm (2.38") or less (Approx. 480 sheets)) (80 g/m <sup>2</sup> , 20 lb. Bond)
	<b>Bypass</b>	Approx. 100 sheets (Reused paper *1 Stack height 5.5 mm (0.20") or less (Approx. 40 sheets)) (80 g/m <sup>2</sup> , 20 lb. Bond)
<b>Exit tray loading capacity</b>		Approx. 500 sheets (80 g/m <sup>2</sup> , 20 lb. Bond)
<b>Toner density adjustment</b>		Magnetic auto-toner system
<b>Exposure control</b>		Automatic plus manual selection from 11 exposure step
<b>USB interface</b>		USB 2.0 (Hi-Speed)
<b>Environment (for normal use)</b>		Temperature: 10 - 30 °C (50 - 86 °F), Humidity: 20 - 85% (No Condensation)
<b>Power requirements and Power consumption (including optional equipments)</b>		AC 220-240 V±10%, 8 A (50/60 Hz): 1.6 kW or less AC 115 V±10%, 12 A (50/60 Hz): 1.5 kW or less
<b>Dimensions (equipment only)</b>		575 mm (22.6") (W) x 586 mm (23.1") (D) x 756 mm (29.8") (H)
<b>Weight</b>		Approx. 59 kg (132.3 lb.)
<b>Space occupied (equipment only)</b>		889 mm (35") (W) x 586 mm (23.1") (D)
<b>Storage capacity</b>		Max. 1000 sheets or until the memory is full (Toshiba's own chart)

- This specification varies depending on the printing conditions, environment and status of the installed options.
- Specifications and appearance are subject to change without notice in the interest of product improvement.

\*1 Paper printed by e-STUDIO306LP and erased by e-STUDIO RD30.



# Specifications of Options

This section describes the specifications of the options sold separately. For details other than the specifications, see  P.58 "Options" in this manual.

## Reversing Automatic Document Feeder

<b>Model name</b>	MR-3026
<b>Copy sides</b>	1-side, Duplex
<b>Number of originals (A4 or LT)</b>	100 originals (35 - 80 g/m <sup>2</sup> , 9.3 - 20 lb. Bond) or 16 mm/0.63" or less in height (more than 80 g/m <sup>2</sup> , 20 lb. Bond)
<b>Feeding speed</b>	45 sheets/min. (600 dpi)
<b>Acceptable originals</b>	A3, A4, A4-R, A5-R, B4, B5, B5-R, FOLIO, LD, LG, LT, LT-R, ST-R, COMP (A5 and ST size are not acceptable.)
<b>Paper weight</b>	1-sided original: 35 - 157 g/m <sup>2</sup> , 9.3 - 41.8 lb., 2-sided original: 50 - 157 g/m <sup>2</sup> , 13.3 - 41.8 lb.
<b>Power source</b>	DC 24 V (supplied from the equipment)
<b>Dimensions</b>	575 mm (22.6") (W) x 528 mm (20.8") (D) x 135 mm (5.3") (H)
<b>Weight</b>	Approx. 12.5 kg (27.6 lb.)
<b>Power consumption</b>	49.5 W max.

## Paper Feed Pedestal (1 drawer type)

<b>Model name</b>	KD-1033
<b>Acceptable paper size</b>	A3, A4, A4-R, A5-R, B4, B5, B5-R, FOLIO, LD, LG, LT, LT-R, ST-R, COMP, 8.5"SQ, 13"LG, 8K, 16K, 16K-R (A5, ST and non-standard size are not acceptable.)
<b>Paper weight</b>	64 - 80 g/m <sup>2</sup> (17 - 20 lb. Bond)
<b>Maximum capacity</b>	550 sheets (80 g/m <sup>2</sup> , 20 lb. Bond)
<b>Power source</b>	DC 5 V, DC 24 V (supplied from the equipment)
<b>Dimensions</b>	660 mm (26") (W) x 701 mm (27.6") (D) x 292 mm (11.5") (H) (incl. Stabilizer)
<b>Weight</b>	Approx. 21 kg (46.3 lb.)

## Additional Drawer Module

<b>Model name</b>	MY-1042
<b>Acceptable paper size</b>	A3, A4, A4-R, A5-R, B4, B5, B5-R, FOLIO, LD, LG, LT, LT-R, ST-R, COMP, 8.5"SQ, 13"LG, 8K, 16K, 16K-R (A5, ST and non-standard size are not acceptable.)
<b>Paper weight</b>	64 - 80 g/m <sup>2</sup> (17 - 20 lb. Bond)
<b>Maximum capacity</b>	550 sheets (80 g/m <sup>2</sup> , 20 lb. Bond), 500 sheets (105 g/m <sup>2</sup> , 24 or 28 lb. Bond)
<b>Weight</b>	Approx. 4.5 kg (9.9 lb.)

## Job Separator (MJ-5009)

<b>Model name</b>		MJ-5009
<b>Acceptable paper size</b>	<b>Standard size</b>	A3, A4, A4-R, A5-R, B4, B5, B5-R, FOLIO, LD, LG, LT, LT-R, ST-R, COMP, 13"LG, 8.5"SQ, 8K, 16K, 16K-R
	<b>Non-Standard size</b>	Length: 100 - 297 mm (3.9 - 11.7"), Width: 148 - 432 mm (5.8 - 17")
<b>Acceptable paper weight</b>	<b>Upper stacker</b>	64 - 80 g/m <sup>2</sup> , 17 - 20 lb. Bond
	<b>Lower stacker</b>	64 - 80 g/m <sup>2</sup> , 17 - 20 lb. Bond
<b>Loading capacity</b>	<b>Upper stacker</b>	25 mm, 0.98" (150 sheets) *2
	<b>Lower stacker</b>	40 mm, 1.57" (250 sheets) *2
<b>Power source</b>		Supplied from the equipment
<b>Dimensions</b>		498 mm (19.6") (W) x 415 mm (16.3") (D) x 153 mm (6.0") (H)
<b>Weight</b>		Approx. 3.3 kg (7.3 lb.)

\*1 The lower stacker is used for paper exiting.

\*2 The value in the parentheses is the number of 80 g/m<sup>2</sup> or 20 lb. Bond sheets.


## FAX Unit

<b>Model Name</b>	GD-1250
<b>Size of Original</b>	A3, A4, A4-R, A5, A5-R, B4, B5, B5-R, FOLIO, LD, LG, LT, LT-R, ST, ST-R, COMP
<b>Recording Paper Size</b>	A3, A4, A4-R, A5-R, B4, B5, B5-R, FOLIO, LD, LG, LT, LT-R, ST-R, COMP
<b>Compatibility Communication Modes</b>	Exclusive Mode, ECM, G3
<b>Communication Resolution</b>	Horizontal: 8 dots/mm, 16 dots/mm, 300 dots/inch
	Vertical: 3.85 lines/mm, 7.7 lines/mm, 15.4 lines/mm, 300 dots/inch
<b>Transmission Rate</b>	33,600/31,200/28,800/26,400/24,000/21,600/19,200/16,800/14,400/12,000/9,600/7,200/4,800/2,400 bps
<b>Encoding Systems</b>	JBIG/MMR/MR/MH
<b>Memory Capacity</b>	Transmission/Reception: 1 GB (HDD) *1
<b>Unit Type</b>	Desktop type, transmitting/receiving dual type
<b>Applicable Network</b>	Public Switched Telephone Network (PSTN)

\*1 For hard drives, MB means 1 million bytes.

(Total HDD accessible capacity may vary depending on operating environment.)

For details of the FAX Unit (GD-1250), refer to the following guide:

 **GD-1250/GD-1260/GD-1270 Operator's Manual for FAX Unit:** "Chapter 1: BEFORE USING FAX"

Toshiba-recommended paper is used for the values above. Specifications and appearance are subject to change without notice in the interest of product improvement.

# INDEX

## A, B

Acceptable paper.....	63
[ACCESS] button.....	8
Additional Drawer Module.....	58, 65
Adjusting the angle of the control panel.....	9
Alarm lamp.....	8
Alert message indication area.....	10
Automatic duplexing unit.....	6
Bypass tray.....	6

## C, D

Charger.....	38
[CLEAR] button.....	8
Client Software.....	56
Client Utilities CD-ROM.....	55
Control panel.....	7, 8
[COPY] button.....	8
Copying.....	20, 46
[COUNTER] button.....	8
Date and time.....	10
Department management.....	60
Description of Each Component.....	6
Digital keys.....	8
Drawer.....	6

## E, F

e-Filing.....	30, 50
[e-FILING] button.....	8
[ENERGY SAVER] button.....	8
energy saving mode.....	14
Error codes.....	42
Exit support tray.....	7
Exit tray.....	7
[EXTENSION] button.....	34
[FAX] button.....	9
Faxing.....	24, 47
FAX Unit.....	58, 66
Front cover.....	6
[FUNCTION CLEAR] button.....	8
Function display.....	10

## H, I, J

[?] (HELP) button.....	10
[INTERRUPT] button.....	8
Items Included in This Product.....	54
Job Separator.....	58, 66
[JOB STATUS] button.....	10

## M, N

MAIN POWER lamp.....	8
Main power switch.....	7
MEMORY RX / LINE lamps.....	8
Menu.....	34
[MENU] button.....	8
Message indication area.....	10
Network interface connector.....	6

## O, P

ON/OFF lamp.....	8
Operator's Manual Pocket.....	6
Options.....	58
Original Cover.....	58
Original glass.....	7, 37
ORIGINAL MODE.....	22, 26
Original scale.....	7
Paper exit stopper.....	7
Paper feed cover (optional).....	6
Paper Feed Pedestal.....	6, 58, 65
Paper holding lever.....	6
Paper Reusable Device.....	58
Paper size indicator.....	6
Placing paper.....	15
Platen sheet.....	7
[POWER] button.....	8, 12
[PRINT] button.....	9
PRINT DATA lamp.....	8
Printing.....	32, 51

## R, S

Recommended paper.....	63
Regular Cleaning.....	37
Replacing Toner Cartridge.....	36
Reversing Automatic Document Feeder.....	6, 58, 65
Role information displayed area.....	34
[SCAN] button.....	9
Scanning.....	28, 46, 48, 49
Scanning area.....	7
Setting letters.....	11
Shutdown.....	13
Specifications.....	64
Specifications of Options.....	65
[START] button.....	8
[STOP] button.....	8
Symbols.....	40

## T, U

Toner Cartridge.....	4, 7, 36
Touch panel.....	7, 9, 10, 40
Turning the power OFF.....	13
Turning the power ON.....	12
USB port.....	7
USB terminal.....	6
[USER FUNCTIONS] button.....	8
User management.....	61
User name display area.....	34

## Trademarks

- The official name of Windows XP is Microsoft Windows XP Operating System.
- The official name of Windows Vista is Microsoft Windows Vista Operating System.
- The official name of Windows 7 is Microsoft Windows 7 Operating System.
- The official name of Windows 8 is Microsoft Windows 8 Operating System.
- The official name of Windows Server 2003 is Microsoft Windows Server 2003 Operating System.
- The official name of Windows Server 2008 is Microsoft Windows Server 2008 Operating System.
- The official name of Windows Server 2012 is Microsoft Windows Server 2012 Operating System.
- Microsoft, Windows, Windows NT, and the brand names and product names of other Microsoft products are trademarks of Microsoft Corporation in the US and other countries.
- Apple, AppleTalk, Macintosh, Mac, Mac OS, Safari, and TrueType are trademarks of Apple Inc. in the US and other countries.
- Adobe, Acrobat, Reader, and PostScript are either registered trademarks or trademarks of Adobe Systems Incorporated in the United States and/or other countries.
- Mozilla, Firefox and the Firefox logo are trademarks or registered trademarks of Mozilla Foundation in the U.S. and other countries.
- IBM, AT and AIX are trademarks of International Business Machines Corporation.
- NOVELL, NetWare and NDS are trademarks of Novell, Inc. in the US.
- FriXion is a trademark of PILOT CORPORATION.
- TopAccess is a trademark of Toshiba Tec Corporation.
- Other company and product names given in this manual or displayed in this software may be the trademarks of their respective companies.



# e-STUDIO306LP



## **TOSHIBA TEC CORPORATION**

1-11-1, OSAKI, SHINAGAWA-KU, TOKYO, 141-8562, JAPAN

