

MULTIFUNCTIONAL DIGITAL SYSTEMS

Network Fax Guide

Preface

Thank you for purchasing TOSHIBA Multifunctional Digital Systems or Multifunctional Digital Color Systems. This manual explains the instructions for N/W-Fax driver. Read this manual before using your Multifunctional Digital Systems or Multifunctional Digital Color Systems. Keep this manual within easy reach, and use it to configure an environment that makes best use of the e-STUDIO's functions.

To use this function, the scanning function (Internet Fax) and printing function (Network Fax) are required. The e-STUDIO455 Series and the e-STUDIO855 Series provide the scanning function and printing function as options. However, these optional functions are already installed in some models.

■ How to read this manual

□ Symbols in this manual

In this manual, some important items are described with the symbols shown below. Be sure to read these items before using this equipment.

WARNING

Indicates a potentially hazardous situation which, if not avoided, could result in death, serious injury, or serious damage, or fire in the equipment or surrounding objects.

CAUTION

Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury, partial damage to the equipment or surrounding objects, or loss of data.

Note

Indicates information to which you should pay attention when operating the equipment.

Other than the above, this manual also describes information that may be useful for the operation of this equipment with the following signage:

Tip

Describes handy information that is useful to know when operating the equipment.



Pages describing items related to what you are currently doing. See these pages as required.

□ Screens and Operation Procedures

- In this manual, the screens and the operation procedures in Windows are described for Windows Vista. The details on the screens may differ depending on how the equipment is used, such as the status of the installed options, the OS version and the applications.
- The illustration screens used in this manual are for paper in the A/B format. If you use paper in the LT format, the display or the order of buttons in the illustrations may differ from that of your equipment.

□ Trademarks

- The official name of Windows 2000 is Microsoft Windows 2000 Operating System.
- The official name of Windows XP is Microsoft Windows XP Operating System.
- The official name of Windows Vista is Microsoft Windows Vista Operating System.
- The official name of Windows 7 is Microsoft Windows 7 Operating System.
- The official name of Windows Server 2003 is Microsoft Windows Server 2003 Operating System.
- The official name of Windows Server 2008 is Microsoft Windows Server 2008 Operating System.
- Microsoft, Windows, Windows NT, and the brand names and product names of other Microsoft products are trademarks of Microsoft Corporation in the US and other countries.
- Apple, AppleTalk, Macintosh, Mac, Mac OS, Safari, and TrueType are trademarks of Apple Inc. in the US and other countries.
- Adobe, Adobe Acrobat, Adobe Reader, Adobe Acrobat Reader, and PostScript are trademarks of Adobe Systems Incorporated.
- Mozilla, Firefox and the Firefox logo are trademarks or registered trademarks of Mozilla Foundation in the U.S. and other countries.
- IBM, AT and AIX are trademarks of International Business Machines Corporation.
- NOVELL, NetWare, and NDS are trademarks of Novell, Inc.
- TopAccess is a trademark of Toshiba Tec Corporation.
- Other company names and product names in this manual are the trademarks of their respective companies.

CONTENTS

Preface.....	1
Chapter 1 OVERVIEW	
Features and Functions	6
Chapter 2 SENDING A FAX	
Basic Procedure	8
Specifying Recipients	10
Entering recipients from the keyboard.....	10
Selecting recipients from the address book.....	11
Selecting recipients from the address book (Search option).....	13
Removing recipients.....	17
Chapter 3 SETTING OPTIONS	
How To Setup.....	20
Setting Initial Values of N/W-Fax driver options	20
Setting print options for each print job	20
Setting up the N/W-Fax Driver Options	21
Setting up the [Send] tab	21
Setting up the [Cover Sheet] tab	22
Setting up the [Sender Information] tab.....	23
Displaying the Version Information.....	24
Sending with Extended Fax Functionality	25
Saving a fax as file	25
Delayed transmission	26
Sending with a cover sheet	27
Chapter 4 APPENDIX	
Cover Sheet Samples	32
Standard Cover Page.....	32
Business Cover Page.....	33
Professional Cover Page.....	34
INDEX	35

OVERVIEW

This chapter describes about the overview of the Network Fax features.

Features and Functions	6
-------------------------------------	----------

Features and Functions

This equipment provides the network fax feature, which simplifies and facilitates your office facsimile needs that enables you to send fax or Internet Fax digital documents directly from your desktop.

Notes

- Fax transmission using the N/W-Fax driver is available only when the optional Fax unit is installed.
- Please enable the SNMP setting on TopAccess to use the N/W-Fax functions. In addition, the N/W-Fax driver does not work if the SNMP setting on TopAccess is disable when the optional Fax unit is installed.

The highly intuitive, network N/W-Fax driver software enables you to select the fax printer driver to electronically faxes or Internet Faxes from your computer to one or more recipients. You can easily define fax job properties from the send list to fax resolutions. The N/W-Fax driver is complimented with the AddressBook Viewer. The combination of applications enables you to easily manage a selection of fax recipients and access to the address book.

The N/W-Fax driver enables you to set up send lists and send electronic documents from your PC to one or more destinations. You send to the fax much the same way you would choose to print to a designated printer that makes using the N/W-Fax driver quick and simple. You can select the fax properties. Fax properties are the attributes you can set to define sender and recipient information for processing fax jobs such as dialing options, sender information, fax resolution and page layout.

Other features include an easy to use fax scheduler that allows you to set up a date and time to transmit your fax. Cover page options are also provided. You can include a customized cover page with your fax transmission that can include sender and recipient fax information and a detailed message. You can easily maintain sender and contact information that can be printed on the cover pages.

Note

Faxing hard-copy documents must be performed from the touch panel display.

Tips

- The image quality of the originals that are sent by the N/W-Fax driver is different from the originals that are sent by the general fax operation.
- If you specify the Email addresses as the recipients using N/W-Fax driver, the document will be sent as an Internet Fax. The Internet Fax feature allows users to send originals, same as the fax features. However, the Internet Fax is sent through the Internet, although the fax is sent through the public switched telephone line. In order to send the Internet Fax, the remote device also must support the Internet Fax feature. For more details about the Internet Fax, refer to the **Scanning Guide**.

SENDING A FAX

This chapter describes how to send a fax using a N/W-Fax driver.

Basic Procedure	8
Specifying Recipients	10
Entering recipients from the keyboard	10
Selecting recipients from the address book	11
Selecting recipients from the address book (Search option)	13
Removing recipients	17

Basic Procedure

The basic procedure for sending a fax (Network Fax / Internet Fax) is as follows.

You can use standard functions or set optional functions as well as the basic ones described in this section. For these operations, see the following section.


📖 P.19 “SETTING OPTIONS”

- 1 Start the application software and prepare a document to be sent.**
- 2 Select [Print] from the [File] menu in the application software.**

Tip

The procedure for displaying the print dialog box may differ from the above depending on the application software.

- 3 Select [TOSHIBA e-STUDIO Series Fax] for the printer and click [Preferences].**




The dialog box of the N/W-Fax driver properties appears.

Tip


Note that the command name to open the driver properties may differ from [Preferences] depending on the application software.

- 4 Click the [Send] tab and specify the recipients.**




- To specify recipients, enter them with the keyboard or select them from the address book.
📖 P.10 “Specifying Recipients”
- On the [Send] tab, you can set the resolution and paper size, etc. as well as specifying recipients.
📖 P.21 “Setting up the [Send] tab”
- On the [Cover Sheet] and [Sender Information Properties] tab, the sender information for adding a fax cover sheet can be set.
📖 P.22 “Setting up the [Cover Sheet] tab”
📖 P.23 “Setting up the [Sender Information] tab”

5 Click [OK].



The transmission settings are determined and the N/W-Fax driver properties dialog box is closed.

6 Click [Print] in the print dialog box on the application software.



A fax starts being sent.

Tips

- Note that the command name to print a document (send a fax) may differ from [Print] depending on the application software.
- A waiting fax job can be checked or deleted through the managing jobs function in TopAccess. A sent fax job can also be checked through the displaying job logs function in TopAccess. For details, refer to the **TopAccess Guide**.

Specifying Recipients

Up to 400 recipients can be specified in a single operation. To send a Network Fax, specify the fax number. To send an Internet Fax, specify the Email address.

📖 P.10 “Entering recipients from the keyboard”

📖 P.11 “Selecting recipients from the address book”

📖 P.13 “Selecting recipients from the address book (Search option)”

📖 P.17 “Removing recipients”

Tip

To use the address book, you need to register recipients in the address book of AddressBook Viewer in advance. For details, refer to the *Operator's Manual for AddressBook Viewer*.


Note

If more than one recipient is specified in a single transmission, and a cover sheet is set in the N/W-Fax driver or a header page is set to be printed on the recipient's device, all the recipient information may be printed. If you want to secure the recipient information, avoid sending a fax to multiple recipients at the same time.

■ Entering recipients from the keyboard


You can enter a recipient with the keyboard.

1 Click [New].



The [Direct Dial] dialog box appears.


2 For the recipient of Network Fax, click [Fax Number] and enter the fax number in the right-hand box. For one of an Internet Fax, click [Internet Fax Address] and enter the Email address in the right-hand box.



Tips

- You can also enter up to 20 digits each in [SUB](sub address) and [PWD](password) when entering a fax number. Entering them enables the document to be transferred from the recipient's device to that of the sub-address, as the communication is in compliance with ITU-T standard. However, in order to use this function, the recipient's device must be a model in compliance with the ITU-T standard.
- Use “ - ” (hyphen) if you send a Network Fax with pauses (approx. 3 seconds) inserted in the fax number.

3 Click [OK].



The recipients selected for “To” are listed.


Tip

When the fax transmission is completed, the recipients are automatically removed from the “To” list.

■ Selecting recipients from the address book


Select a recipient from the address book in the AddressBook Viewer.

1 Click [Select From Address Book].



The AddressBook Viewer runs.

2 When selecting a fax number after selecting a contact from the contact list, click [Select Fax] and when selecting an Email address, click [Select Email].



The selected recipients are listed in the “Selected Fax” or “Selected Email”.

Note

A contact, for which only a fax number is registered, cannot be displayed in the “Selected Email” and a contact, for which only an Email address is registered, cannot be displayed in the “Selected Fax”.

You can select a recipient by the following operations:

Selecting a contact by dragging and dropping

Drag a contact in the contact list and drop it to the “Selected Fax” or “Selected Email”.

Selecting a contact by double-clicking on it


Double-click on a contact in the contact list. To change the setting of the recipient to be selected upon double-clicking, select [Default Configuration], [Type Selection] in the [View] menu and then one of [Fax], [Email] and [Both].

Selecting a contact from a shortcut menu

Right-click on the contact in the contact list, select [Select] from the shortcut menu and then either [Fax Number] and [Email].

Removing a recipient

Select a recipient in the “Selected Fax” or “Selected Email” and click the corresponding [Remove] (Left: fax number, Right: Email address).

3 Click [OK].

The AddressBook Viewer is closed and the recipients selected for “To” are listed.


Tip

When the fax transmission is completed, the recipients are automatically removed from the “To” list.

■ Selecting recipients from the address book (Search option)


You can find and select a recipient from the address book in the AddressBook Viewer.

1 Click [Select From Address Book].




The AddressBook Viewer runs.

2 Select [Find] from the [Edit] menu.



The [Find Contact] dialog box appears.


3 Select a registered directory service in [Data Source].



Tip

To change the setting of the default address book in the [Data Source] box, select [View] - [Default Configuration] - [Data Source] and then choose an address book.

4 Display the [Person] tab and enter search strings in the following boxes.



Display Name — To search display names, enter a search string here.

Fax Number — To search fax numbers, enter the numbers here.


Email — To search Email address, enter a search string here.

If you perform searching in the above conditions, proceed to step 6. If you want to set more detailed search conditions, proceed to step 5 and set the [Detail Setting] tab. Note that even if you enter the search conditions in both the [Person] and [Detail Setting] tabs, you cannot perform searching in these combined conditions.

Tip

In the [Person] tab, you do not have to fill in all the boxes and the string does not need to completely correspond to the target of the search. Entering one or more characters in one or more boxes causes a search to be made for contacts which correspond to the particular conditions.

5 Display the [Detail Setting] tab, set the search condition, and then click [Add].




Field Select — Select an item to be searched.

Condition of search string — Select a condition in the left-hand box, and then enter a search string in the right-hand box.

- The search condition is displayed in the “Condition list”.
- To set more than one search condition, repeat this operation as many times as needed.
- To delete the search conditions, select one and click [Delete].

6 Click [Search].




- It starts searching contacts in the selected address book. When the search is complete, the contacts matching the search conditions are listed.
- To stop searching, click [Stop].

Note

Even if you enter the search conditions in both the [Person] and [Detail Setting] tabs, only the search condition in the tab currently displayed is used. You cannot perform searching in the combined conditions on both tabs.

7 Drag and drop the contacts to “Selected Fax” or “Selected Email” from the list of the search results.



The selected recipients are listed in “Selected Fax” or “Selected Email”.

Note

A contact, for which only a fax number is registered, cannot be displayed in the “Selected Email” and a contact, for which only an Email address is registered, cannot be displayed in the “Selected Fax”.

You can select a recipient by the following operations:

Selecting a contact by double-clicking on it

Double-click on a contact in the list of the search results. To change the setting of the recipient to be selected upon double-clicking, select [Default Configuration], [Type Selection] in the [View] menu and then one of [Fax], [Email] and [Both].


Selecting a contact from a shortcut menu

Right-click on the contact in the list of the search results, select [Select] from the shortcut menu and then either [Fax Number] or [Email].

Removing a recipient

Select a recipient in the “Selected Fax” or “Selected Email” and click the corresponding [Remove] (Left: fax number, Right: Email address).

8 Click [OK].



The AddressBook Viewer is closed and the recipients selected for “To” are displayed on the list.


Tip

When the fax transmission is completed, the recipients are automatically removed from the “To” list.

■ Removing recipients

You can remove a recipient from the “To” list in the N/W-Fax driver properties.

1 Select a recipient and click [Remove].



The selected recipient is removed.

SETTING OPTIONS

This chapter describes how to set up options for N/W-Fax driver.

How To Setup	20
Setting Initial Values of N/W-Fax driver options	20
Setting print options for each print job	20
Setting up the N/W-Fax Driver Options	21
Setting up the [Send] tab	21
Setting up the [Cover Sheet] tab	22
Setting up the [Sender Information] tab	23
Displaying the Version Information	24
Sending with Extended Fax Functionality	25
Saving a fax as file	25
Delayed transmission	26
Sending with a cover sheet	27

How To Setup

There are two ways to set the N/W-Fax driver options: One is to set the initial values of the options and the other is to set each option for each individual job.

📖 P.20 “Setting Initial Values of N/W-Fax driver options”

📖 P.20 “Setting print options for each print job”

■ Setting Initial Values of N/W-Fax driver options

Setting the N/W-Fax options by displaying the N/W-Fax driver properties from the Printers folder on the Windows [Start] menu will establish the initial values of the options.

1 Click the start button, [Control Panel] and select [Printers].

When using Windows 2000/XP/Server 2003, click [Start] and select [Printers and Faxes].

When using Windows 7, click [Start] and select [Devices and Printers].

2 Select the N/W-Fax driver, click the [File] menu and select [Printing Preferences].

■ Setting print options for each print job

Setting the N/W-Fax driver options by displaying the printer properties from the Print dialog box within an application will establish the values for the current N/W-Fax job. The N/W-Fax driver option settings specific to each N/W-Fax job are set using this method.

1 Click the [File] menu and select [Print] on an application.

2 Select [TOSHIBA e-STUDIO Series Fax] and click [Properties] or [Preferences].


Setting up the N/W-Fax Driver Options

N/W-Fax driver options are the attributes to define the way a fax job is transmitted. For example, you can specify the recipients, resolution, and paper size.

- 📖 P.21 “Setting up the [Send] tab”
- 📖 P.22 “Setting up the [Cover Sheet] tab”
- 📖 P.23 “Setting up the [Sender Information] tab”
- 📖 P.24 “Displaying the Version Information”

■ Setting up the [Send] tab

In the [Send] tab, you can specify the recipients and how the fax will be sent.



- 1) **To**
This displays the specified recipients list.
📖 P.10 “Specifying Recipients”
- 2) **[Select From Address Book]**
Click to launch the AddressBook Viewer. You can select recipients from the address book.
📖 P.11 “Selecting recipients from the address book”
- 3) **[New]**
Click to add new recipient by entering manually. The [Direct Dial] dialog box appears.
📖 P.10 “Entering recipients from the keyboard”
- 4) **[Remove]**
Select a recipient in the [To] list and click this to remove the recipient from the list.
📖 P.17 “Removing recipients”
- 5) **Resolution**
Select the resolution for the fax.
 - **Standard (200 x 100 dpi)** — Select this to send a document in Standard mode (200 x 100 dpi).
 - **Fine (200 x 200 dpi)** — Select this to send a document in Fine mode (200 x 200 dpi).
 - **Super Fine (200 x 400 dpi)** — Select this to send a document in Super Fine mode (200 x 400 dpi).
 - **Ultra Fine (400 x 400 dpi)** — Select this to send a document in Ultra Fine mode (400 x 400 dpi).
- 6) **Dept. Code**
Enter 5-digit department code if required. When the department code is enabled on this equipment, you must enter the department code to send a fax.

Notes

- If you do not enter the department code when the department code is enabled on the equipment and the Department Code Enforcement is set to ON in TopAccess, the job will be stored in the Invalid job list without transmitting the job. You can release or delete the job that is stored in the Invalid job list from the [JOB STATUS] button on the touch panel. For instructions on how to release or delete the job in the Invalid job list, refer to **Printing Guide**.
- If you do not enter the department code when the department code is enabled on the equipment and the Department Code Enforcement is set to PRINT in TopAccess, the job will be sent.
- If you do not enter the department code when the department code is enabled on the equipment and the Department Code Enforcement is set to DELETE in TopAccess, the job will be deleted automatically.

- 7) **Paper Size**
Select the paper size of your document.

8) Orientation

Select the orientation of your document.

9) Save as File

Select this to save up to 10 GB documents in the "FILE_SHARE" folder in the equipment as well as send the document as a fax and Internet Fax.

 P.25 "Saving a fax as file"

Tip

When the cover sheet is set, the cover sheet and the original will be stored in the "FILE_SHARE" folder.

10) File Format

Select the file format of the document that will be saved. This option can be selected only when the [Save as File] check box is selected.

11) Delayed Fax


Select whether sending a document now or later.


- **Send Fax Now** — Select this to send a document immediately.
- **Send Fax Later** — Select this to send a document on a specified date and time. When this is selected, click [Edit] to display the [Scheduled Time] dialog box and specify date and time the job will be transmitted. The job sent to this equipment will be stored in the Fax queue until the specified date and time.

 P.26 "Delayed transmission"


■ Setting up the [Cover Sheet] tab

In the [Cover Sheet] tab, you can specify the fax cover sheet to be sent. If you enable the cover sheet, the cover sheet is attached in the first page of the document and sent to the recipients.

 P.27 "Sending with a cover sheet"

**1) Cover Sheet**

Select the cover sheet type from [Standard Cover Page], [Business Cover Page], and [Professional Cover Page]. For cover sheet samples, see the Appendix at the end of this guide.

 P.32 "Cover Sheet Samples"

2) Font Name

Select the font to be used for the cover sheet.

3) Subject


Enter the subject to be displayed on the cover sheet. You can enter up to 40 characters.

4) Message

Enter the message to be displayed on the cover sheet. You can enter up to 500 characters.

5) Sender Information

Check this to print sender information on the cover sheet. When this is enabled, specify the sender information in the [Sender Information] tab.

 P.23 "Setting up the [Sender Information] tab"

6) Recipient Information

Check this to have recipient information appear on the cover sheet. Select one or more of the following options to determine what information will appear in the "To:" field of the cover sheet.


- **Name** — Check this to have the recipient name appear on the cover sheet.
- **Company** — Check this to have the recipient company name appear on the cover sheet.
- **Department Name** — Check this to have the recipient department name appear on the cover sheet.
- **Fax Number** — Check this to have the recipient fax number or Email address appear on the cover sheet.

7) Reference Number

Enter the reference number to identify the fax. This number will appear on the cover sheet.

■ Setting up the [Sender Information] tab

In the [Sender Information] tab, you can specify the sender information that appears on the cover sheet. This must be set only when the [Sender Information] check box in the [Cover Sheet] tab is selected.

**1) Text box**

You can enter up to 500 characters in this text box.

2) [SNMP Settings]


Click this button if a community name other than "public" (default) is set for the SNMP community name for your TOSHIBA MFP.

The [SNMP Settings] dialog box appears so that you can change the SNMP community name.


Note

To send fax jobs normally, the SNMP community names must be the same in the following 3 settings. For help, consult the administrator.

- Your TOSHIBA MFP
- [SNMP Settings] dialog box of the [Sender Information] tab




- TCP/IP port of the [Ports] tab in the N/W-Fax driver



■ Displaying the Version Information

In the [About] tab, you can display the version information for the N/W-Fax driver.



Sending with Extended Fax Functionality


The N/W-Fax driver allows users to perform the following features.

- 📖 P.25 “Saving a fax as file”
- 📖 P.26 “Delayed transmission”
- 📖 P.27 “Sending with a cover sheet”


■ Saving a fax as file

You can save a document in the “TXFAX” folder in the “FILE_SHARE” folder in this equipment as well as sending the document to fax numbers and Email addresses.

1 Display the [Send] tab and select the [Save as File] check box.



2 Select the file format in the [File Format] box.



3 Specify the other options to send a document and click [OK].

4 Click [OK] (or [Print]) to send a document to this equipment.

The document is saved in the “TXFAX” folder in the “FILE_SHARE” folder in this equipment.


Tips

- The saved file contains the cover sheet when the cover sheet is set.
- Since the image smoothing function does not work for the image stored in the “FILE_SHARE” folder, its printing image quality differs from the normal fax image quality.

■ Delayed transmission

When the delayed transmission is specified, the fax is stored in the fax queue in this equipment and will be sent on the specified date and time.


1 Display the [Send] tab and select [Send Fax Later] in the [Delayed Fax] box.



2 Click [Edit].

The [Scheduled Time] dialog box appears.

3 Select the date and time and click [OK].



- You can click the Date arrow to display a calendar then allows you to select an date.
- Enter the time to commence the fax transmission. You can use the up and down arrows to assist with setting the time with the proper format.

Note

The scheduled date cannot be more than one month from the current date. If the current month does not have a date like the current date, then the date will be set at the last day of the following month. For example, if the current date is March 31st, then the maximum date that can be selected for the scheduled fax is April 30th.

4 Specify the other options to send a document and click [OK].

5 Click [OK] (or [Print]) to send a document to this equipment.

■ Sending with a cover sheet

You can choose to send a cover sheet with your fax transmission. The cover sheet is merged with the recipient [To] list data to create a fax cover sheet. You can select what to include on the cover sheet such as sender or recipient information.


Note

When a printer driver whose name consists of 54 letters or more is specified for the default printer and an attempt is made to send a fax with a cover sheet added from Microsoft Excel using a N/W-Fax driver with an IPP port, an XL error may occur and fax transmission may be impossible. (This error does not occur in application software other than Microsoft Excel.)

If this error occurs, perform one of the following and start sending a fax again.

- Use 30 letters or less for the N/W Fax driver name.
- Do not attach any cover sheet.


1 Display the [Cover Sheet] tab and select the cover sheet type in the [Cover Sheet] box.



For samples of the cover sheets, see the Appendix at the end of this guide.


P.32 “Cover Sheet Samples”

2 Select the font in the [Font Name] box.




The selected font applies to the text contents in the cover sheet.

3 Enter the subject to be displayed on the cover sheet in the [Subject] box.




You can enter up to 40 characters for the subject.

4 Enter the message to be displayed on the cover sheet in the [Message] box.




You can enter up to 500 characters for the message.


5 If you want the sender information to appear on the cover sheet, select the [Sender Information] check box.



If you check this, click the [Sender Information] tab and enter the sender information in the text box. You can enter up to 500 characters in the sender information text box.



6 If you want the recipients information to appear on the cover sheet, check the [Recipients Information] check box and check the items required for the recipient information.



Name — Check this to have the name of the recipient appear on the cover sheet.

Company — Check this to have the company name of the recipient appear on the cover sheet.


Department Name — Check this to have the department name of the recipient appear on the cover sheet.

Fax Number — Check this to have the fax number or Email address of the recipient appear on the cover sheet.

Notes

- Recipients information is obtained from the address book. If the recipient is added manually, this information does not appear on the cover sheet except for the fax number or Email address.
- The recipients information for all recipients will appear on the cover sheet.

- 7** If you want the reference number to identify the document to appear on the cover sheet, select the [Reference Number] check box and enter the reference number in the text box.



The screenshot shows a dialog box with the following options checked:

- Sender Information
- Recipients Information
- Name
- Company
- Department Name
- Fax Number
- Reference Number: [000000001]

Buttons at the bottom: OK, Cancel, Help.

You can enter up to 20 characters for the reference number.

- 8** Specify the other options to send a document and click [OK].
- 9** Click [Print] to send a document to this equipment.

APPENDIX

This chapter shows the cover sheet samples.

Cover Sheet Samples	32
Standard Cover Page	32
Business Cover Page.....	33
Professional Cover Page.....	34

Cover Sheet Samples

■ Standard Cover Page

<p style="text-align: center;">FACSIMILE TRANSMITTAL</p> <p>Reference Number: 0000000000000000</p> <p>To: 00000000001</p> <p>From: MFP-00C67861</p> <p>Subject: N/W-Fax Document</p> <p>Message: This is a N/W-Fax Document.</p>

■ Business Cover Page**FACSIMILE TRANSMITTAL SHEET**

Reference Number:

0000000000000000

To:

00000000001

From:

MFP-00C67861

Subject:

N/W-Fax Document

Message:

This is a N/W-Fax Document.

■ Professional Cover Page

FACSIMILE TRANSMITTAL SHEET

Reference Number:
0000000000000000

To:
00000000001

From:
MFP-00C67861

Subject:
N/W-Fax Document

Message:
This is a N/W-Fax Document.

INDEX

A		T	
address book	11, 13	To	21
AddressBook Viewer	11, 13	V	
B		Version Information	24
Basic Procedure	8		
Business Cover Page	33		
C			
Cover Sheet	22		
[Cover Sheet] tab	22		
D			
Delayed Fax	22		
[Delayed Fax] box	26		
Dept. Code	21		
F			
Features and Functions	6		
File Format	22		
[File Format] box	25		
Font Name	22		
[Font Name] box	27		
I			
Initial Values	20		
M			
Message	22		
[Message] box	28		
N			
N/W-Fax Driver Options	21		
[New]	10, 21		
O			
Orientation	22		
P			
Paper Size	21		
Professional Cover Page	34		
PWD	10		
R			
Recipient Information	23		
[Recipients Information] check box	28		
Reference Number	23		
[Reference Number] check box	29		
[Remove]	21		
Removing recipients	17		
Resolution	21		
S			
Save as File	22		
[Save as File] check box	25		
[Select From Address Book]	21		
[Send] tab	21		
Sender Information	22		
[Sender Information] check box	28		
[Sender Information] tab	23		
[SNMP Settings]	23		
Specifying Recipients	10		
Standard Cover Page	32		
SUB	10		
Subject	22		
[Subject] box	27		

FC-5520C/6520C/6530C
FC-2020C/2330C/2820C/2830C/3520C/3530C/4520C
DP-2090/2520/3000/3570/4570
DP-5550/6550/7550/8550
OME080026D0

MULTIFUNCTIONAL DIGITAL SYSTEMS
Network Fax Guide

TOSHIBA TEC CORPORATION

2-17-2, HIGASHIGOTANDA, SHINAGAWA-KU, TOKYO, 141-8664, JAPAN

